

Network Working Group
Request for Comments: 2155
Category: Standards Track

B. Clouston
Cisco Systems
B. Moore
IBM Corporation
June 1997

Definitions of Managed Objects
for APPN using SMIV2

Status of this Memo

This document specifies an Internet standards track protocol for the Internet community, and requests discussion and suggestions for improvements. Please refer to the current edition of the "Internet Official Protocol Standards" (STD 1) for the standardization state and status of this protocol. Distribution of this memo is unlimited.

Table of Contents

1.	Introduction	1
2.	The SNMPv2 Network Management Framework	1
3.	Overview	2
3.1	APPN MIB structure	4
4.	Definitions	9
5.	Acknowledgments	122
6.	References	122
7.	Security Considerations	123
8.	Author's Addresses	124

1. Introduction

This memo defines a portion of the Management Information Base (MIB) for use with network management protocols in the Internet community. In particular, it defines objects for monitoring and controlling network devices with APPN (Advanced Peer-to-Peer Networking) capabilities. This memo identifies managed objects for the APPN protocol.

2. The SNMPv2 Network Management Framework

The SNMP Network Management Framework consists of several components. For the purpose of this specification, the applicable components of the Framework are the SMI and related documents [1, 2, 3], which define the mechanisms used for describing and naming objects for the purpose of management.

The Framework permits new objects to be defined for the purpose of experimentation and evaluation.

3. Overview

This document identifies a set of objects for monitoring the configuration and active characteristics of devices with APPN capabilities, and for controlling certain characteristics. APPN is the aspect of Systems Network Architecture (SNA) that supports peer-to-peer networking. These networks transport both independent and dependent LU session traffic. See the SNANAU APPC MIB [7] and the SNA NAU MIB [8] for management of these sessions. See also the DLUR MIB[9], and the HPR MIB[10] for management of extensions to the APPN architecture. In this document, we describe APPN managed objects.

An APPN network comprises various types of nodes, and transmission groups (TGs) that connect the nodes. Network nodes (NNs) provide directory and routing functions for session establishment. NNs may be session end points or intermediate nodes in a session. A border node is a type of network node that connects networks together for session establishment without fully merging them. End nodes (ENs) are session end points that receive directory and routing functions from network nodes, over control-point to control-point (CP-CP) sessions. Low-entry networking (LEN) nodes are also session end points, but do not support CP-CP sessions, and therefore need additional manual configuration definitions to establish sessions in an APPN network. ENs and LEN nodes may have minimal directory and routing functions to establish control sessions (ENs) or to connect into the APPN network (LEN nodes). Virtual routing nodes (VRNs) are not really nodes, but rather common definitions among actual nodes in a shared transport facility such as a local area network (LAN) that allow these actual nodes to temporarily establish a logical link with one another without defining each other's link-level addressing information.

Ports and link stations are the node's interface to the data link control (DLC), which provides the physical transport, or to another protocol such as Data Link Switching (DLSw), which provides transport over an IP network. See the SNADLC SDLC MIB[11], the SNADLC LLC MIB[12], and the DLSw MIB[13]. A link station uses a port to make a connection to another node. This connection establishes a TG between the two nodes.

The directory and routing functions enable an NN to find where an LU is located in the network, and calculate the optimal route for the session based on the requested class of service (COS). A network node saves the LU information in a directory database, which is built from LUs defined locally, LU registration from served end nodes, and LUs learned from network searches.

Each NN maintains a local COS database that assigns a routing weight, or relative cost, to each resource for each class of service. For example, the #INTER COS assigns a lower weight to TGs with a greater effective capacity, while the #BATCH COS favors TGs with a lower relative cost per byte.

A node saves network topology information (on NNs, VRNs, and TGs between them) in a network topology database. The topology information includes state and routing characteristics. Topology information is exchanged between NNs over CP-CP sessions such that the database is fully replicated at each NN. Information on TGs from NNs to ENs are kept in a local topology database. Local topology information is shared with other NNs only during the session establishment process, to give the NN responsible for route calculation the necessary information for end-to-end route calculation.

SNA names such as LU names, CP names, COS names, and mode names can be padded with blanks (space characters) in SNA formats. These blanks are nonsignificant. For example, in a BIND Request Unit (RU) a COS name of "#INTER" with a length of 6 is identical to a COS name of "#INTER " with a length of 8. However, in this MIB, nonsignificant blanks are not included by the agent. Using the COS name from the previous example, an agent would return a length of 6 and the string "#INTER" with no blanks for appnCosName, regardless of how it appears in the BIND RU or in internal storage. The lone exception is the all blank mode name, for which the agent returns a length of 8 and the string " " (8 blank spaces). The MIB variables that this applies to are identified by a textual convention syntax that also describes this behavior.

When an SNA name is functioning as a table index, an agent treats trailing blanks as significant. If a management station requests the objects from a row with index "#INTER ", the agent does not match this to the row with index "#INTER". Since an agent has no nonsignificant blanks in any of its table indices, the only reason for a Management Station to include them would be to start GetNext processing at a chosen point in a table. For example, a GetNext request with index "M " would start retrieval from a table at the first row with an 8-character index beginning with "M" or a letter after "M".

The SNA/APPN terms and overall architecture are documented in [4], [5], [6], and [14].

Highlights of the management functions supported by the APPN MIB module include the following:

- o Activating and deactivating ports and link stations.
- o Monitoring of configuration parameters related to the node, ports, link stations, virtual routing nodes, and classes of service.
- o Monitoring of operational parameters related to ports, link stations, virtual routing nodes, topology, directory, and intermediate sessions.
- o Historical information about link station errors during connection establishment, or that caused the connection to terminate.
- o Deactivating intermediate sessions.
- o Traps for SNA Management Services (SNA/MS) Alert conditions.

This MIB module does not support:

- o Configuration of APPN nodes.
- o Monitoring and control of endpoint sessions.
- o Dependent LU Requester (DLUR) management.
- o High-Performance Routing (HPR) management.

3.1. APPN MIB Structure

The APPN MIB module contains the following groups of objects:

- o appnNode - objects related to the APPN node for all node types.
- o appnNn - objects to represent the network nodes, virtual routing nodes, and TGs between these nodes that make up the APPN network topology database maintained in NNS.
- o appnLocalTopology - objects to represent nodes and TGs between nodes in the local topology database maintained in all nodes.

- o appnDir - objects related to LU location information from the node's directory database.
- o appnCos - objects related to classes of service information.
- o appnSessIntermediate - objects related to intermediate sessions that pass through this node.

These groups are described below in more detail.

3.1.1. appnNode group

The appnNode group consists of the following tables and objects:

1) appnGeneralInfoAndCaps

This group of objects describes general information about the APPN node. The type of information includes the node type and the time since this node was initialized.

2) appnNnUniqueInfoAndCaps

This group of objects describes information specific to network nodes such as node routing characteristics.

3) appnEnUniqueInfoAndCaps

This group of objects describes information specific to end nodes, including its network node server.

4) appnPortInformation

This includes the appnPortTable, which describes the configuration and current status of the ports used by APPN, including the port state and DLC type.

5) appnLinkStationInformation

This includes the appnNodeLsTable, which describes the configuration and current status of the link stations used by APPN, including the link state and port name; and the appnLsStatusTable, which provides information about errors this node encountered with connections to adjacent nodes, such as the sense data captured during connection failures. It is a product option to decide how many appnLsStatusTable entries are kept.

6) appnVrnInfo

This includes the appnVrnTable, which describes the relationship between virtual routing nodes' TGs described in the appnLocalTgTable with ports in the appnPortTable.

3.1.2. appnNn group

The appnNn group consists of the following objects and tables

1) appnNnTopo

These objects contain general information about the network topology database including the number of nodes present, and the number of topology database updates (TDU) wars the node has detected.

2) appnNnTopology

This includes tables representing the APPN network topology database. This includes the network nodes, virtual routing nodes, and TGs between these nodes, as well as the information about these resources carried in topology updates. The tables are first indexed by the same flow reduction sequence number (FRSN) used in topology exchanges between NNs. This allows a management station to retrieve only incremental updates, since the agent will update the FRSN of new or changed resources.

3.1.3. appnLocalTopology group

The appnLocalTopology group consists of the following objects and tables:

1) appnLocalThisNode

a) appnLocalGeneral

Contains the local node and type.

b) appnLocalNnSpecific

These objects contain routing information about the local network node.

c) appnLocalTg

This table represents information about this node's local TGs.

2) appnLocalEnTopology

This table represents TG information for EN TGs learned by the NN via TG registration with the local node.

3.1.4. appnDir group

The appnDir group consists of the following objects and tables:

1) appnDirPerf

These objects represent information related to information about the directory database and directory searches involving this node.

2) appnDirTable

This table represents the directory database, listing LUs known to this node, along with the owning node of the LU and the serving NN of the owning node.

3.1.5. appnCos group

The appnCos group consists of the following tables:

1) appnCosModeTable

This table represents the mode to class of service mapping.

2) appnCosNameTable

This table represents the transmission priority for each class of service.

3) appnCosNodeRowTable

This table represents the node-row information for each class of service, including the weight of each node.

3) appnCosTGRowTable

This table represents the TG-row information for each class of service, including the weight of each TG.

3.1.6. appnSessIntermediate group

The appnSessIntermediate group consists of the following objects and tables:

- 1) appnIsInGlobal

These objects allow control of the collection of intermediate session information such as Route Selection Control Vectors (RSCVs) and counters.

- 2) appnIsInTable

This table contains information on active intermediate sessions.

- 3) appnIsRtpTable

This table contains information on active intermediate sessions that are being transported on Rapid Transport Protocol (RTP) connections by High Performance Routing (HPR).

3.1.7. appnTraps

One APPN trap is defined. It is intended to correspond to SNA/MS Alerts, but is optional for a product to implement this trap. The trap identifies the Alert ID number and, where possible, the affected resource.

4. Definitions

```
APPN-MIB DEFINITIONS ::= BEGIN

IMPORTS

IANAifType
FROM IANAifType-MIB

DisplayString, VariablePointer, RowPointer, DateAndTime,
TruthValue, TimeStamp, TEXTUAL-CONVENTION
FROM SNMPv2-TC

experimental, Counter32, Gauge32, Integer32, Unsigned32,
TimeTicks, OBJECT-TYPE, MODULE-IDENTITY, NOTIFICATION-TYPE
FROM SNMPv2-SMI

MODULE-COMPLIANCE, OBJECT-GROUP, NOTIFICATION-GROUP
FROM SNMPv2-CONF

snanauMIB
FROM SNA-NAU-MIB;

appnMIB MODULE-IDENTITY
LAST-UPDATED "9703201200Z"
ORGANIZATION "IETF SNA NAU MIB WG / AIW APPN MIBs SIG"
CONTACT-INFO

"

Bob Clouston
Cisco Systems
7025 Kit Creek Road
P.O. Box 14987
Research Triangle Park, NC 27709, USA
Tel: 1 919 472 2333
E-mail: clouston@cisco.com

Bob Moore
IBM Corporation
800 Park Offices Drive
RHJA/664
P.O. Box 12195
Research Triangle Park, NC 27709, USA
Tel: 1 919 254 4436
E-mail: remoore@ralvm6.vnet.ibm.com

"
DESCRIPTION
```

"This is the MIB module for objects used to manage network devices with APPN capabilities."

```
 ::= { snanauMIB 4 }
-- snanauMIB ::= { mib-2 34 }

-- ****
-- Textual Conventions
-- ****
SnaNodeIdentification ::= TEXTUAL-CONVENTION
    STATUS current
    DESCRIPTION
        "An SNA Node Identification consists of two parts, which together comprise four bytes of hexadecimal data. In SNA the Node Identification is transported in bytes 2-5 of the XID.

The block number is the first three digits of the Node Identification. These 3 hexadecimal digits identify the product.

The ID number is the last 5 digits of the Node Identification. These 5 hexadecimal digits are administratively defined and combined with the 3-digit block number form the 8-digit Node Identification. A unique value is required for connections to SNA subarea. In some implementations, the value 'bbb00000' (where 'bbb' represents a 3-digit block number) is returned to mean that the ID number is not unique on this node.

An SNA Node Identification is represented as eight ASCII-encoded hexadecimal digits, using the characters '0' - '9' and 'A' - 'F'."
```

SYNTAX OCTET STRING (SIZE (8))

```
SnaControlPointName ::= TEXTUAL-CONVENTION
    STATUS current
    DESCRIPTION
        "A fully qualified SNA control point name, consisting of a 1 to 8 character network identifier (NetId), a period ('.'), and a 1 to 8 character control point name (CpName)."
```

The NetId and CpName are constructed from the uppercase letters 'A' - 'Z' and the numerics '0' - '9', all encoded in ASCII, with the restriction that the first character of each must be a letter. Trailing blanks are not allowed.

Earlier versions of SNA permitted three additional characters in NetIds and CpNames: '#', '@', and '\$'. While this use of

these characters has been retired, a Management Station should still accept them for backward compatibility."

SYNTAX OCTET STRING (SIZE (3..17))

SnaClassOfServiceName ::= TEXTUAL-CONVENTION

 STATUS current

 DESCRIPTION

 "An SNA class-of-service (COS) name, ranging from 1 to 8 ASCII characters. COS names take one of two forms:

- a user-defined COS name is constructed from the uppercase letters 'A' - 'Z' and the numerics '0' - '9', with the restriction that the first character of the name must be a letter.
- an SNA-defined user-session COS name begins with the character '#', which is followed by up to seven additional characters from the set of uppercase letters and numerics.

Trailing blanks are not allowed in either form of COS name.

A zero-length string indicates that a COS name is not available."

SYNTAX OCTET STRING (SIZE (0..8))

SnaModeName ::= TEXTUAL-CONVENTION

 STATUS current

 DESCRIPTION

 "An SNA mode name, ranging from 1 to 8 ASCII characters. Mode names take one of two forms:

- a user-defined mode name is constructed from the uppercase letters 'A' - 'Z' and the numerics '0' - '9', with the restriction that the first character of the name must be a letter.
- an SNA-defined user-session mode name begins with the character '#', which is followed by up to seven additional characters from the set of uppercase letters and numerics.

Trailing blanks are not allowed in either form of mode name, with the single exception of the all-blank mode name, where a string consisting of 8 blanks is returned.

A zero-length string indicates that a mode name is not available."

SYNTAX OCTET STRING (SIZE (0..8))

SnaSenseData ::= TEXTUAL-CONVENTION
 STATUS current
 DESCRIPTION
 "To facilitate their display by a Management Station, sense data objects in the MIB are represented as OCTET STRINGS containing eight ASCII characters. Eight '0' characters indicates that no sense data identifying an SNA error condition is available."

An SNA sense data is represented as eight hexadecimal digits, using the characters '0' - '9' and 'A' - 'F'."

SYNTAX OCTET STRING (SIZE (8))

DisplayableDlcAddress ::= TEXTUAL-CONVENTION
 STATUS current
 DESCRIPTION
 "DLC address of a port or link station, represented as an OCTET STRING containing 0 to 64 ASCII characters.
 A Management Station should use a value of this type only for display. The 'real' DLC address, i.e., the sequence of bytes that flow in the DLC header, is often available in a DLC-specific MIB.

The zero-length string indicates that the DLC address in question is not known to the agent."

SYNTAX OCTET STRING (SIZE (0..64))

AppnNodeCounter ::= TEXTUAL-CONVENTION
 STATUS current
 DESCRIPTION
 "An object providing global statistics for the entire APPN node. A Management Station can detect discontinuities in this counter by monitoring the appnNodeCounterDisconTime object."

SYNTAX Counter32

AppnPortCounter ::= TEXTUAL-CONVENTION
 STATUS current
 DESCRIPTION
 "An object providing statistics for an APPN port. A Management Station can detect discontinuities in this counter by monitoring the appnPortCounterDisconTime object."

SYNTAX Counter32

AppnLinkStationCounter ::= TEXTUAL-CONVENTION
 STATUS current
 DESCRIPTION
 >An object providing statistics for an APPN link station. A Management Station can detect discontinuities in this counter by monitoring the appnLsCounterDisconTime object."

SYNTAX Counter32

AppnTopologyEntryTimeLeft ::= TEXTUAL-CONVENTION
 STATUS current
 DESCRIPTION
 >Number of days before deletion of this entry from the topology database. Range is 0-15. A value of 0 indicates that the entry is either in the process of being deleted, or is being marked for deletion at the next garbage collection cycle."

SYNTAX INTEGER (0..15)

AppnTgDlcData ::= TEXTUAL-CONVENTION
 STATUS current
 DESCRIPTION
 >DLC-specific data related to a connection network transmission group. For other TGSs, a zero-length string is returned.

Examples of the type of data returned by an object with this syntax include the following:

Token-Ring	- MAC/SAP
X.25 Switched	- dial digits
X.21 Switched	- dial digits
Circuit Switch	- dial digits

This MIB does not specify formats for these or any other types of DLC-specific data. Formats may, however, be specified in documents related to a particular DLC.

The contents of an object with this syntax correspond to the contents of the DLC-specific subfields of cv46, documented in (6)."

SYNTAX OCTET STRING (SIZE (0..64))

AppnTgEffectiveCapacity ::= TEXTUAL-CONVENTION
 STATUS current
 DESCRIPTION
 >A value representing the effective capacity of a transmission group. This is an administratively assigned value derived from

the link bandwidth and maximum load factor. It is encoded in the same way as byte 7 of cv47, and represents a floating-point number in units of 300 bits per second."

SYNTAX OCTET STRING (SIZE (1))

```
AppnTgSecurity ::= TEXTUAL-CONVENTION
  STATUS current
  DESCRIPTION
    "A value representing the level of security on a transmission
     group. A class of service definition includes an indication of
     the acceptable TG security value(s) for that class of service.
```

The following seven values are defined:

```
nonsecure(1) -
  (X'01'): none of the values listed below;
            for example, satellite-connected or
            located in a nonsecure country
publicSwitchedNetwork(32) -
  (X'20'): public switched network; secure
            in the sense that there is no
            predetermined route that traffic will take
undergroundCable(64) -
  (X'40'): underground cable; located in a
            secure country (as determined by the
            network administrator)
secureConduit(96) -
  (X'60'): secure conduit, not guarded; for
            example, pressurized pipe
guardedConduit(128) -
  (X'80'): guarded conduit; protected
            against physical tapping
encrypted(160) -
  (X'A0'): link-level encryption is provided
guardedRadiation(192) -
  (X'C0'): guarded conduit containing the
            transmission medium; protected against
            physical and radiation tapping"
```

```
SYNTAX INTEGER {
  nonsecure(1),           -- X'01'
  publicSwitchedNetwork(32), -- X'20'
  undergroundCable(64),   -- X'40'
  secureConduit(96),     -- X'60'
  guardedConduit(128),   -- X'80'
  encrypted(160),         -- X'A0'
  guardedRadiation(192)  -- X'C0'
```

}

AppnTgDelay ::= TEXTUAL-CONVENTION

 STATUS current

 DESCRIPTION

 "Relative amount of time that it takes for a signal to travel the length of a logical link. This time is represented in microseconds, using the same encoding scheme used in cv47 in a topology update. Some of the more common values, along with their encoded hex values, are:

minimum(0),	X'00'
negligible(384),	X'4C'
terrestrial(9216),	X'71'
packet(147456),	X'91'
long(294912),	X'99'
maximum(2013265920)	X'FF'

"

SYNTAX OCTET STRING (SIZE (1))

-- **** appnObjects OBJECT IDENTIFIER ::= { appnMIB 1 }
-- ****

-- ***** The APPN Node Group *****

appnNode	OBJECT IDENTIFIER ::= { appnObjects 1 }
appnGeneralInfoAndCaps	OBJECT IDENTIFIER ::= { appnNode 1 }
appnNnUniqueInfoAndCaps	OBJECT IDENTIFIER ::= { appnNode 2 }
appnEnUniqueCaps	OBJECT IDENTIFIER ::= { appnNode 3 }
appnPortInformation	OBJECT IDENTIFIER ::= { appnNode 4 }
appnLinkStationInformation	OBJECT IDENTIFIER ::= { appnNode 5 }
appnVrnInfo	OBJECT IDENTIFIER ::= { appnNode 6 }

-- This group provides global information about an APPN network node,
-- an APPN end node, or an LEN node.

-- The first section applies to all three node types.
-- The second section applies only to APPN network nodes.
-- The third section applies only to APPN end nodes and to LEN nodes.
-- The fourth section applies to all three node types.
-- The fifth section applies to all three node types.
-- The sixth section applies only to APPN network nodes.

-- APPN General Information
-- This section applies to both APPN network and end nodes, and to

```
-- LEN end nodes.

appnNodeCpName OBJECT-TYPE
    SYNTAX SnaControlPointName
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "Administratively assigned network name for this node."
    ::= { appnGeneralInfoAndCaps 1 }

appnNodeMibVersion OBJECT-TYPE
    SYNTAX DisplayString (SIZE (11))
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "The value of LAST-UPDATED from this module's MODULE-IDENTITY
         macro. This object gives a Management Station an easy way of
         determining the level of the MIB supported by an agent."
    ::= { appnGeneralInfoAndCaps 2 }

appnNodeId OBJECT-TYPE
    SYNTAX SnaNodeIdentification
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "This node's Node Identification, which it sends in bytes
         2-5 of XID."
    ::= { appnGeneralInfoAndCaps 3 }

appnNodeType OBJECT-TYPE
    SYNTAX INTEGER {
        networkNode(1),
        endNode(2),
        t21len(4)
    }
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "Type of APPN node:
            networkNode(1) - APPN network node
            endNode(2)      - APPN end node
            t21len(4)       - LEN end node"
    ::= { appnGeneralInfoAndCaps 4 }
```

```
appnNodeUpTime OBJECT-TYPE
    SYNTAX TimeTicks
    UNITS "hundredths of a second"
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "Amount of time (in hundredths of a second) since the APPN node
         was last re-initialized."
    ::= { appnGeneralInfoAndCaps 5 }

appnNodeParallelTg OBJECT-TYPE
    SYNTAX TruthValue
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "Indicates whether this node supports parallel TGS."
    ::= { appnGeneralInfoAndCaps 6 }

appnNodeAdaptiveBindPacing OBJECT-TYPE
    SYNTAX TruthValue
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "Indicates whether this node supports adaptive bind pacing for
         dependent LUs."
    ::= { appnGeneralInfoAndCaps 7 }

appnNodeHprSupport OBJECT-TYPE
    SYNTAX INTEGER {
        noHprSupport(1),
        hprBaseOnly(2),
        rtpTower(3),
        controlFlowsOverRtpTower(4)
    }
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "Indicates this node's level of support for high-performance
         routing (HPR):"

        noHprSupport(1)                      - no HPR support
        hprBaseOnly(2)                       - HPR base (option set 1400)
                                                supported
        rtpTower(3)                          - HPR base and RTP tower
                                                (option set 1401) supported
```

```
controlFlowsOverRtpTower(4) - HPR base, RTP tower, and  
control flows over RTP  
(option set 1402) supported
```

This object corresponds to cv4580, byte 9, bits 3-4."

```
::= { appnGeneralInfoAndCaps 8 }
```

```
appnNodeMaxSessPerRtpConn OBJECT-TYPE  
SYNTAX Gauge32  
MAX-ACCESS read-only  
STATUS current  
DESCRIPTION  
"This object represents a configuration parameter indicating  
the maximum number of sessions that the APPN node is to put on  
any HPR connection. The value is zero if not applicable."
```

```
::= { appnGeneralInfoAndCaps 9 }
```

```
appnNodeHprIntRteSetups OBJECT-TYPE  
SYNTAX AppnNodeCounter  
MAX-ACCESS read-only  
STATUS current  
DESCRIPTION  
"The total number of HPR route setups received for routes  
passing through this node since the node was last  
re-initialized."
```

```
::= { appnGeneralInfoAndCaps 10 }
```

```
appnNodeHprIntRteRejects OBJECT-TYPE  
SYNTAX AppnNodeCounter  
MAX-ACCESS read-only  
STATUS current  
DESCRIPTION  
"The number of HPR route setups rejected by this node for  
routes passing through it since the node was last  
re-initialized."
```

```
::= { appnGeneralInfoAndCaps 11 }
```

```
appnNodeHprOrgRteSetups OBJECT-TYPE  
SYNTAX AppnNodeCounter  
MAX-ACCESS read-only  
STATUS current  
DESCRIPTION  
"The total number of HPR route setups sent for routes  
originating in this node since the node was last
```

```
re-initialized."  
 ::= { appnGeneralInfoAndCaps 12 }  
  
appnNodeHprOrgRteRejects OBJECT-TYPE  
  SYNTAX AppnNodeCounter  
  MAX-ACCESS read-only  
  STATUS current  
  DESCRIPTION  
    "The number of HPR route setups rejected by other nodes for  
    routes originating in this node since the node was last  
    re-initialized."  
 ::= { appnGeneralInfoAndCaps 13 }  
  
appnNodeHprEndRteSetups OBJECT-TYPE  
  SYNTAX AppnNodeCounter  
  MAX-ACCESS read-only  
  STATUS current  
  DESCRIPTION  
    "The total number of HPR route setups received for routes  
    ending in this node since the node was last re-initialized."  
 ::= { appnGeneralInfoAndCaps 14 }  
  
appnNodeHprEndRteRejects OBJECT-TYPE  
  SYNTAX AppnNodeCounter  
  MAX-ACCESS read-only  
  STATUS current  
  DESCRIPTION  
    "The number of HPR route setups rejected by this node for  
    routes ending in it since the node was last re-initialized."  
 ::= { appnGeneralInfoAndCaps 15 }  
  
appnNodeCounterDisconTime OBJECT-TYPE  
  SYNTAX TimeStamp  
  MAX-ACCESS read-only  
  STATUS current  
  DESCRIPTION  
    "The value of the sysUpTime object the last time the APPN node  
    was re-initialized."  
 ::= { appnGeneralInfoAndCaps 16 }  
  
-- ****  
-- APPN Network Node Information
```

-- This section provides global information about an APPN network node.

```
appnNodeNnCentralDirectory OBJECT-TYPE
    SYNTAX TruthValue
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "Indicates whether this node supports central directory
         services.

        This object corresponds to cv4580, byte 8, bit 1.

::= { appnNnUniqueInfoAndCaps 1 }

appnNodeNnTreeCache OBJECT-TYPE
    SYNTAX INTEGER {
        noCache(1),
        cacheNoIncrUpdate(2),
        cacheWithIncrUpdate(3)
    }
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "Indicates this node's level of support for caching of route
         trees. Three levels are specified:

        noCache(1)          - caching of route trees is not
                               supported
        cacheNoIncrUpdate(2) - caching of route trees is
                               supported, but without incremental
                               updates
        cacheWithIncrUpdate(3) - caching of route trees with
                               incremental updates is supported"

::= { appnNnUniqueInfoAndCaps 2 }
```

```
appnNodeNnRouteAddResist OBJECT-TYPE
    SYNTAX INTEGER (0..255)
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "Route addition resistance.
```

This administratively assigned value indicates the relative desirability of using this node for intermediate session traffic. The value, which can be any integer 0-255, is used in route computation. The lower the value, the more desirable the node is for intermediate routing.

This object corresponds to cv4580, byte 6."

`::= { appnNnUniqueInfoAndCaps 3 }`

`appnNodeNnIsr` OBJECT-TYPE

SYNTAX TruthValue

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Indicates whether the node supports intermediate session routing.

This object corresponds to cv4580, byte 8, bit 2."

`::= { appnNnUniqueInfoAndCaps 4 }`

`appnNodeNnFrsn` OBJECT-TYPE

SYNTAX Unsigned32

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The last flow-reduction sequence number (FRSN) sent by this node in a topology update to an adjacent network node."

`::= { appnNnUniqueInfoAndCaps 5 }`

`appnNodeNnPeriBorderSup` OBJECT-TYPE

SYNTAX TruthValue

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Indicates whether this node has peripheral border node support.

This object corresponds to cv4580, byte 9, bit 0."

`::= { appnNnUniqueInfoAndCaps 6 }`

`appnNodeNnInterchangeSup` OBJECT-TYPE

SYNTAX TruthValue

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Indicates whether this node has interchange node support.

This object corresponds to cv4580, byte 9, bit 1."

`::= { appnNnUniqueInfoAndCaps 7 }`

```
appnNodeNnExteBorderSup OBJECT-TYPE
    SYNTAX TruthValue
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "Indicates whether this node has extended border node support.
```

This object corresponds to cv4580, byte 9, bit 2."

```
::= { appnNnUniqueInfoAndCaps 8 }
```

```
appnNodeNnSafeStoreFreq OBJECT-TYPE
    SYNTAX INTEGER (0..32767)
    UNITS "TDUS"
    MAX-ACCESS read-write
    STATUS current
    DESCRIPTION
        "The topology safe store frequency.
```

If this number is not zero, then the topology database is saved each time the total number of topology database updates (TDUs) received by this node increases by this number. A value of zero indicates that the topology database is not being saved."

```
::= { appnNnUniqueInfoAndCaps 9 }
```

```
appnNodeNnRsn OBJECT-TYPE
    SYNTAX Unsigned32
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "Resource sequence number for this node, which it assigns and controls.
```

This object corresponds to the numeric value in cv4580, bytes 2-5."

```
::= { appnNnUniqueInfoAndCaps 10 }
```

```
appnNodeNnCongested OBJECT-TYPE
    SYNTAX TruthValue
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "Indicates whether this node is congested. Other network nodes stop routing traffic to this node while this flag is on.
```

This object corresponds to cv4580, byte 7, bit 0."

::= { appnNnUniqueInfoAndCaps 11 }

appnNodeNnIsrDepleted OBJECT-TYPE

SYNTAX TruthValue

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Indicate whether intermediated session routing resources are depleted. Other network nodes stop routing traffic through this node while this flag is on.

This object corresponds to cv4580, byte 7, bit 1."

::= { appnNnUniqueInfoAndCaps 12 }

appnNodeNnQuiescing OBJECT-TYPE

SYNTAX TruthValue

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Indicates whether the node is quiescing.

This object corresponds to cv4580, byte 7, bit 5."

::= { appnNnUniqueInfoAndCaps 13 }

appnNodeNnGateway OBJECT-TYPE

SYNTAX TruthValue

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Indicates whether the node has gateway services support.

This object corresponds to cv4580, byte 8, bit 0."

::= { appnNnUniqueInfoAndCaps 14 }

-- *****
-- APPN End Node Information

appnNodeEnModeCosMap OBJECT-TYPE

SYNTAX TruthValue

MAX-ACCESS read-only

STATUS current

DESCRIPTION

```
"Indicates whether this end node supports mode name to COS name
mapping."  
 ::= { appnEnUniqueCaps 1 }  
  
appnNodeEnNnServer OBJECT-TYPE  
    SYNTAX OCTET STRING (SIZE (0 | 3..17))  
    MAX-ACCESS read-only  
    STATUS current  
    DESCRIPTION  
        "The fully qualified name of the current NN server for this end  
        node. An NN server is identified using the format specified in  
        the SnaControlPointName textual convention. The value is a  
        zero-length string when there is no active NN server."  
    ::= { appnEnUniqueCaps 2 }  
  
appnNodeEnLuSearch OBJECT-TYPE  
    SYNTAX TruthValue  
    MAX-ACCESS read-only  
    STATUS current  
    DESCRIPTION  
        "Indicates whether the node is to be searched for LUs as part  
        of a network broadcast search."  
    ::= { appnEnUniqueCaps 3 }  
  
-- *****  
-- APPN Port information  
--  
  
appnPortTable OBJECT-TYPE  
    SYNTAX SEQUENCE OF AppnPortEntry  
    MAX-ACCESS not-accessible  
    STATUS current  
    DESCRIPTION  
        "The Port table describes the configuration and current status  
        of the ports used by APPN. When it is known to the APPN  
        component, an OBJECT IDENTIFIER pointing to additional  
        information related to the port is included. This may, but  
        need not, be a RowPointer to an ifTable entry for a DLC  
        interface immediately 'below' the port."  
    ::= { appnPortInformation 1 }  
  
appnPortEntry OBJECT-TYPE  
    SYNTAX AppnPortEntry  
    MAX-ACCESS not-accessible
```

```

STATUS current
DESCRIPTION
  "The port name is used as the index to this table."

INDEX
  { appnPortName }

 ::= { appnPortTable 1 }

AppnPortEntry ::= SEQUENCE {
  appnPortName           DisplayString,
  appnPortCommand         INTEGER,
  appnPortOperState       INTEGER,
  appnPortDlcType         IANAifType,
  appnPortPortType        INTEGER,
  appnPortSIMRIM          TruthValue,
  appnPortLsRole           INTEGER,
  appnPortNegotLs          TruthValue,
  appnPortDynamicLinkSupport TruthValue,
  appnPortMaxRcvBtuSize    INTEGER,
  appnPortMaxIframeWindow  Gauge32,
  appnPortDefLsGoodXids   AppnPortCounter,
  appnPortDefLsBadXids    AppnPortCounter,
  appnPortDynLsGoodXids   AppnPortCounter,
  appnPortDynLsBadXids   AppnPortCounter,
  appnPortSpecific         RowPointer,
  appnPortDlcLocalAddr    DisplayableDlcAddress,
  appnPortCounterDisconTime TimeStamp
}

appnPortName OBJECT-TYPE
  SYNTAX DisplayString (SIZE (1..10))
  MAX-ACCESS not-accessible
  STATUS current
  DESCRIPTION
    "Administratively assigned name for this APPN port."
  ::= { appnPortEntry 1 }

appnPortCommand OBJECT-TYPE
  SYNTAX INTEGER {
    deactivate(1),
    activate(2),
    recycle(3),
    ready(4)
  }
  MAX-ACCESS read-write
  STATUS current

```

DESCRIPTION

"Object by which a Management Station can activate, deactivate, or recycle (i.e., cause to be deactivated and then immediately activated) a port, by setting the value to activate(1), deactivate(2), or recycle(3), respectively. The value ready(4) is returned on GET operations until a SET has been processed; after that the value received on the most recent SET is returned."

```
::= { appnPortEntry 2 }
```

appnPortOperState OBJECT-TYPE

SYNTAX INTEGER {
 inactive(1),
 pendactive(2),
 active(3),
 pendinact(4)
 }

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Indicates the current state of this port:

inactive(1)	- port is inactive
pendactive(2)	- port is pending active
active(3)	- port is active
pendinact(4)	- port is pending inactive"

```
::= { appnPortEntry 3 }
```

appnPortDlcType OBJECT-TYPE

SYNTAX IANAifType
MAX-ACCESS read-only
STATUS current
DESCRIPTION

"The type of DLC interface, distinguished according to the protocol immediately 'below' this layer."

```
::= { appnPortEntry 4 }
```

appnPortPortType OBJECT-TYPE

SYNTAX INTEGER {
 leased(1),
 switched(2),
 sharedAccessFacilities(3)
 }
MAX-ACCESS read-only

```

STATUS current
DESCRIPTION
  "Identifies the type of line used by this port:

  leased(1)          - leased line
  switched(2)         - switched line
  sharedAccessFacilities(3) - shared access facility, such
                             as a LAN.

 ::= { appnPortEntry 5 }

appnPortSIMRIM OBJECT-TYPE
  SYNTAX TruthValue
  MAX-ACCESS read-only
  STATUS current
  DESCRIPTION
    "Indicates whether Set Initialization Mode (SIM) and Receive
     Initialization Mode (RIM) are supported for this port.

 ::= { appnPortEntry 6 }

appnPortLsRole OBJECT-TYPE
  SYNTAX INTEGER {
    primary(1),
    secondary(2),
    negotiable(3),
    abm(4)
  }
  MAX-ACCESS read-only
  STATUS current
  DESCRIPTION
    "Initial role for link stations activated through this port.
     The values map to the following settings in the initial XID,
     where 'ABM' indicates asynchronous balanced mode and 'NRM'
     indicated normal response mode:

    primary(1): ABM support = 0      ( = NRM)
                 role = 01            ( = primary)
    secondary(2): ABM support = 0      ( = NRM)
                  role = 00            ( = secondary)
    negotiable(3): ABM support = 0     ( = NRM)
                   role = 11           ( = negotiable)
    abm(4):       ABM support = 1      ( = ABM)
                 role = 11           ( = negotiable)"

 ::= { appnPortEntry 7 }

appnPortNegotLs OBJECT-TYPE

```

```
SYNTAX TruthValue
MAX-ACCESS read-only
STATUS current
DESCRIPTION
  "Indicates whether the node supports negotiable link stations
   for this port."
 ::= { appnPortEntry 8 }

appnPortDynamicLinkSupport OBJECT-TYPE
  SYNTAX TruthValue
  MAX-ACCESS read-only
  STATUS current
  DESCRIPTION
    "Indicates whether this node allows call-in on this port from
     nodes not defined locally."
 ::= { appnPortEntry 9 }

appnPortMaxRcvBtuSize OBJECT-TYPE
  SYNTAX INTEGER (99..32767)
  UNITS "bytes"
  MAX-ACCESS read-only
  STATUS current
  DESCRIPTION
    "Maximum Basic Transmission Unit (BTU) size that a link station
     on this port can receive.

     This object corresponds to bytes 21-22 of XID3."
 ::= { appnPortEntry 10 }

appnPortMaxIframeWindow OBJECT-TYPE
  SYNTAX Gauge32
  UNITS "I-frames"
  MAX-ACCESS read-only
  STATUS current
  DESCRIPTION
    "Maximum number of I-frames that can be received by the XID
     sender before an acknowledgement is received."
 ::= { appnPortEntry 11 }

appnPortDefLsGoodXids OBJECT-TYPE
  SYNTAX AppnPortCounter
  UNITS "XID exchanges"
  MAX-ACCESS read-only
  STATUS current
```

DESCRIPTION

"The total number of successful XID exchanges that have occurred on all defined link stations on this port since the last time this port was started."

```
::= { appnPortEntry 12 }
```

appnPortDefLsBadXids OBJECT-TYPE

SYNTAX AppnPortCounter

UNITS "XID exchanges"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The total number of unsuccessful XID exchanges that have occurred on all defined link stations on this port since the last time this port was started."

```
::= { appnPortEntry 13 }
```

appnPortDynLsGoodXids OBJECT-TYPE

SYNTAX AppnPortCounter

UNITS "XID exchanges"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The total number of successful XID exchanges that have occurred on all dynamic link stations on this port since the last time this port was started."

```
::= { appnPortEntry 14 }
```

appnPortDynLsBadXids OBJECT-TYPE

SYNTAX AppnPortCounter

UNITS "XID exchanges"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The total number of unsuccessful XID exchanges that have occurred on all dynamic link stations on this port since the last time this port was started."

```
::= { appnPortEntry 15 }
```

appnPortSpecific OBJECT-TYPE

SYNTAX RowPointer

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Identifies the object, e.g., one in a DLC-specific MIB, that can provide additional information related to this port. If the agent is unable to identify such an object, the value 0.0 is returned."

`::= { appnPortEntry 16 }`

appnPortDlcLocalAddr OBJECT-TYPE
SYNTAX DisplayableDlcAddress
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"Local DLC address of this port."

`::= { appnPortEntry 17 }`

appnPortCounterDisconTime OBJECT-TYPE
SYNTAX TimeStamp
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"The value of the sysUpTime object the last time the port was started."

`::= { appnPortEntry 18 }`

-- *****
-- APPN Link Station Information
--

appnLsTable OBJECT-TYPE
SYNTAX SEQUENCE OF AppnLsEntry
MAX-ACCESS not-accessible
STATUS current
DESCRIPTION
"This table contains detailed information about the link station configuration and its current status."

`::= { appnLinkStationInformation 1 }`

appnLsEntry OBJECT-TYPE
SYNTAX AppnLsEntry
MAX-ACCESS not-accessible
STATUS current
DESCRIPTION
"This table is indexed by the link station name."

INDEX

```

{ appnLsName }

 ::= { appnLsTable 1 }

AppnLsEntry ::= SEQUENCE {
    appnLsName             DisplayString,
    appnLsCommand          INTEGER,
    appnLsOperState         INTEGER,
    appnLsPortName          DisplayString,
    appnLsDlcType           IANAifType,
    appnLsDynamic           TruthValue,
    appnLsAdjCpName         OCTET STRING,
    appnLsAdjNodeType       INTEGER,
    appnLsTgNum              INTEGER,
    appnLsLimResource        TruthValue,
    appnLsActOnDemand        TruthValue,
    appnLsMigration          TruthValue,
    appnLsPartnerNodeId     SnaNodeIdentification,
    appnLsCpCpSessionSupport TruthValue,
    appnLsMaxSendBtuSize     INTEGER,
-- performance data
    appnLsInXidBytes         AppnLinkStationCounter,
    appnLsInMsgBytes          AppnLinkStationCounter,
    appnLsInXidFrames         AppnLinkStationCounter,
    appnLsInMsgFrames         AppnLinkStationCounter,
    appnLsOutXidBytes         AppnLinkStationCounter,
    appnLsOutMsgBytes          AppnLinkStationCounter,
    appnLsOutXidFrames        AppnLinkStationCounter,
    appnLsOutMsgFrames        AppnLinkStationCounter,
-- propagation delay
    appnLsEchoRspS           AppnLinkStationCounter,
    appnLsCurrentDelay        Gauge32,
    appnLsMaxDelay            Gauge32,
    appnLsMinDelay            Gauge32,
    appnLsMaxDelayTime        DateAndTime,
-- XID Statistics
    appnLsGoodXids           AppnLinkStationCounter,
    appnLsBadXids             AppnLinkStationCounter,
-- DLC-specific
    appnLsSpecific            RowPointer,
    appnLsActiveTime          Unsigned32,
    appnLsCurrentStateTime    TimeTicks,
-- HPR-specific
    appnLsHprSup               INTEGER,
    appnLsErrRecoSup          TruthValue,

```

```

appnLsForAnrLabel          OCTET STRING,
appnLsRevAnrLabel          OCTET STRING,
appnLsCpCpNceId           OCTET STRING,
appnLsRouteNceId          OCTET STRING,
appnLsBfNceId              OCTET STRING,

appnLsLocalAddr            DisplayableDlcAddress,
appnLsRemoteAddr           DisplayableDlcAddress,
appnLsRemoteLsName          DisplayString,
appnLsCounterDisconTime    TimeStamp
}

appnLsName OBJECT-TYPE
SYNTAX DisplayString (SIZE (1..10))
MAX-ACCESS not-accessible
STATUS current
DESCRIPTION
  "Administratively assigned name for the link station.
  The name can be from one to ten characters."
 ::= { appnLsEntry 1 }

appnLsCommand OBJECT-TYPE
SYNTAX INTEGER {
  deactivate(1),
  activate(2),
  recycle(3),
  ready(4)
}
MAX-ACCESS read-write
STATUS current
DESCRIPTION
  "Object by which a Management Station can activate, deactivate,
  or recycle (i.e., cause to be deactivated and then immediately
  reactivated) a link station, by setting the value to
  activate(1), deactivate(2), or recycle(3), respectively. The
  value ready(4) is returned on GET operations until a SET has
  been processed; after that the value received on the most
  recent SET is returned."
 ::= { appnLsEntry 2 }

appnLsOperState OBJECT-TYPE
SYNTAX INTEGER {
  inactive(1),
  sentConnectOut(2),      -- pending active
  pendXidExch(3),        -- pending active
  sendActAs(4),           -- pending active
}

```

```
    sendSetMode(5),      -- pending active
    otherPendingActive(6),-- pending active
    active(7),
    sentDeactAsOrd(8),   -- pending inactive
    sentDiscOrd(9),      -- pending inactive
    sentDiscImmed(10),    -- pending inactive
    otherPendingInact(11) -- pending inactive
}
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"State of this link station. The comments map these more
granular states to the 'traditional' four states for SNA
resources. Values (2) through (5) represent the normal
progression of states when a link station is being activated.
Value (6) represents some other state of a link station in
the process of being activated. Values (8) through (10)
represent different ways a link station can be deactivated.
Value (11) represents some other state of a link station in
the process of being deactivated."
 ::= { appnLsEntry 3 }

appnLsPortName OBJECT-TYPE
SYNTAX DisplayString (SIZE (1..10))
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"Administratively assigned name for the port associated with
this link station. The name can be from one to ten
characters."
 ::= { appnLsEntry 4 }

appnLsDlcType OBJECT-TYPE
SYNTAX IANAifType
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"The type of DLC interface, distinguished according to the
protocol immediately 'below' this layer."
 ::= { appnLsEntry 5 }

appnLsDynamic OBJECT-TYPE
SYNTAX TruthValue
MAX-ACCESS read-only
STATUS current
```

DESCRIPTION

"Identifies whether this is a dynamic link station. Dynamic link stations are created when links that have not been locally defined are established by adjacent nodes."

```
::= { appnLsEntry 6 }
```

appnLsAdjCpName OBJECT-TYPE

SYNTAX OCTET STRING (SIZE (0 | 3..17))

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Fully qualified name of the adjacent node for this link station. An adjacent node is identified using the format specified in the SnaControlPointName textual convention.

The value of this object is determined as follows:

1. If the adjacent node's name was received on XID, it is returned.
2. If the adjacent node's name was not received on XID, but a locally-defined value is available, it is returned.
3. Otherwise a string of length 0 is returned, indicating that no name is known for the adjacent node."

```
::= { appnLsEntry 7 }
```

appnLsAdjNodeType OBJECT-TYPE

SYNTAX INTEGER {

networkNode(1),
endNode(2),
t21len(4),
unknown(255)
}

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Node type of the adjacent node on this link:

networkNode(1) - APPN network node
endNode(2) - APPN end node
t21len(4) - LEN end node
unknown(255) - the agent does not know the node type of the adjacent node

"

```
 ::= { appnLsEntry 8 }

appnLsTgNum OBJECT-TYPE
    SYNTAX INTEGER (0..256)
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "Number associated with the TG to this link station, with a
         range from 0 to 256. A value of 256 indicates that the TG
         number has not been negotiated and is unknown at this time."

 ::= { appnLsEntry 9 }

appnLsLimResource OBJECT-TYPE
    SYNTAX TruthValue
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "Indicates whether the link station is a limited resource. A
         link station that is a limited resource is deactivated when it
         is no longer in use."

 ::= { appnLsEntry 10 }

appnLsActOnDemand OBJECT-TYPE
    SYNTAX TruthValue
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "Indicates whether the link station is activatable on demand.

        Such a link station is reported in the topology as active
        regardless of its actual state, so that it can be considered in
        route calculations. If the link station is inactive and is
        chosen for a route, it will be activated at that time.

 ::= { appnLsEntry 11 }

appnLsMigration OBJECT-TYPE
    SYNTAX TruthValue
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "Indicates whether this link station will be used for
        connections to down-level or migration partners.

        In general, migration nodes do not append their CP names on
        XID3. Such nodes: (1) will not support parallel TGs, (2)
```

should be sent an ACTIVATE PHYSICAL UNIT (ACTPU), provided that the partner supports ACTPUs, and (3) should not be sent segmented BINDs. However, if this node receives an XID3 with an appended CP name, then the partner node will not be treated as a migration node.

In the case of DYNAMIC TGs this object should be set to 'no'."

```
::= { appnLsEntry 12 }
```

appnLsPartnerNodeId OBJECT-TYPE
 SYNTAX SnaNodeIdentification
 MAX-ACCESS read-only
 STATUS current
 DESCRIPTION
 "The partner's Node Identification, from bytes 2-5 of the XID received from the partner. If this value is not available, then the characters '00000000' are returned."

```
::= { appnLsEntry 13 }
```

appnLsCpCpSessionSupport OBJECT-TYPE
 SYNTAX TruthValue
 MAX-ACCESS read-only
 STATUS current
 DESCRIPTION
 "Indicates whether CP-CP sessions are supported by this link station. For a dynamic link, this object represents the default ('Admin') value."

```
::= { appnLsEntry 14 }
```

appnLsMaxSendBtuSize OBJECT-TYPE
 SYNTAX INTEGER (99..32767)
 UNITS "bytes"
 MAX-ACCESS read-only
 STATUS current
 DESCRIPTION
 "Numeric value between 99 and 32767 inclusive indicating the maximum number of bytes in a Basic Transmission Unit (BTU) sent on this link."

When the link state (returned by the appnLsOperState object) is inactive or pending active, the value configured at this node is returned. When the link state is active, the value that was negotiated for it is returned. This negotiated value is the smaller of the value configured at this node and the partner's maximum receive BTU length, received in XID."

```
 ::= { appnLsEntry 15 }

appnLsInXidBytes OBJECT-TYPE
    SYNTAX AppnLinkStationCounter
    UNITS "bytes"
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "Number of XID bytes received. All of the bytes in the SNA
         basic transmission unit (BTU), i.e., all of the bytes in the
         DLC XID Information Field, are counted."

 ::= { appnLsEntry 16 }

appnLsInMsgBytes OBJECT-TYPE
    SYNTAX AppnLinkStationCounter
    UNITS "bytes"
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "Number of message (I-frame) bytes received. All of the bytes
         in the SNA basic transmission unit (BTU), including the
         transmission header (TH), are counted."

 ::= { appnLsEntry 17 }

appnLsInXidFrames OBJECT-TYPE
    SYNTAX AppnLinkStationCounter
    UNITS "XID frames"
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "Number of XID frames received."

 ::= { appnLsEntry 18 }

appnLsInMsgFrames OBJECT-TYPE
    SYNTAX AppnLinkStationCounter
    UNITS "I-frames"
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "Number of message (I-frame) frames received."

 ::= { appnLsEntry 19 }

appnLsOutXidBytes OBJECT-TYPE
    SYNTAX AppnLinkStationCounter
```

```
UNITS "bytes"
MAX-ACCESS read-only
STATUS current
DESCRIPTION
  "Number of XID bytes sent. All of the bytes in the SNA basic
  transmission unit (BTU), i.e., all of the bytes in the DLC XID
  Information Field, are counted."
 ::= { appnLsEntry 20 }

appnLsOutMsgBytes OBJECT-TYPE
  SYNTAX AppnLinkStationCounter
  UNITS "bytes"
  MAX-ACCESS read-only
  STATUS current
  DESCRIPTION
    "Number of message (I-frame) bytes sent. All of the bytes
    in the SNA basic transmission unit (BTU), including the
    transmission header (TH), are counted."
 ::= { appnLsEntry 21 }

appnLsOutXidFrames OBJECT-TYPE
  SYNTAX AppnLinkStationCounter
  UNITS "XID frames"
  MAX-ACCESS read-only
  STATUS current
  DESCRIPTION
    "Number of XID frames sent."
 ::= { appnLsEntry 22 }

appnLsOutMsgFrames OBJECT-TYPE
  SYNTAX AppnLinkStationCounter
  UNITS "I-frames"
  MAX-ACCESS read-only
  STATUS current
  DESCRIPTION
    "Number of message (I-frame) frames sent."
 ::= { appnLsEntry 23 }

appnLsEchoRspns OBJECT-TYPE
  SYNTAX AppnLinkStationCounter
  UNITS "echo responses"
  MAX-ACCESS read-only
  STATUS current
  DESCRIPTION
```

"Number of echo responses returned from adjacent link station. A response should be returned for each test frame sent by this node. Test frames are sent to adjacent nodes periodically to verify connectivity and to measure the actual round trip time, that is, the time interval from when the test frame is sent until when the response is received."

::= { appnLsEntry 24 }

appnLsCurrentDelay OBJECT-TYPE

SYNTAX Gauge32

UNITS "milliseconds"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The time that it took for the last test signal to be sent and returned from this link station to the adjacent link station. This time is represented in milliseconds."

::= { appnLsEntry 25 }

appnLsMaxDelay OBJECT-TYPE

SYNTAX Gauge32

UNITS "milliseconds"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The longest time it took for a test signal to be sent and returned from this link station to the adjacent link station. This time is represented in milliseconds .

The value 0 is returned if no test signal has been sent and returned."

::= { appnLsEntry 26 }

appnLsMinDelay OBJECT-TYPE

SYNTAX Gauge32

UNITS "milliseconds"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The shortest time it took for a test signal to be sent and returned from this link station to the adjacent link station. This time is represented in milliseconds.

The value 0 is returned if no test signal has been sent and

returned."

::= { appnLsEntry 27 }

appnLsMaxDelayTime OBJECT-TYPE

SYNTAX DateAndTime

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The time when the longest delay occurred. This time can be used to identify when this high water mark occurred in relation to other events in the APPN node, for example, the time at which an APPC session was either terminated or failed to be established. This latter time is available in the appcHistSessTime object in the APPC MIB.

The value 00000000 is returned if no test signal has been sent and returned."

::= { appnLsEntry 28 }

appnLsGoodXids OBJECT-TYPE

SYNTAX AppnLinkStationCounter

UNITS "XID exchanges"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The total number of successful XID exchanges that have occurred on this link station since the time it was started."

::= { appnLsEntry 29 }

appnLsBadXids OBJECT-TYPE

SYNTAX AppnLinkStationCounter

UNITS "XID exchanges"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The total number of unsuccessful XID exchanges that have occurred on this link station since the time it was started."

::= { appnLsEntry 30 }

appnLsSpecific OBJECT-TYPE

SYNTAX RowPointer

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Identifies the object, e.g., one in a DLC-specific MIB, that can provide additional information related to this link station.

If the agent is unable to identify such an object, the value 0.0 is returned."

`::= { appnLsEntry 31 }`

`appnLsActiveTime OBJECT-TYPE`

SYNTAX Unsigned32

UNITS "hundredths of a second"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The cumulative amount of time since the node was last re-initialized, measured in hundredths of a second, that this link station has been in the active state. A zero value indicates that the link station has never been active since the node was last re-initialized."

`::= { appnLsEntry 32 }`

`appnLsCurrentStateTime OBJECT-TYPE`

SYNTAX TimeTicks

UNITS "hundredths of a second"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The amount of time, measured in hundredths of a second, that the link station has been in its current state."

`::= { appnLsEntry 33 }`

`appnLsHprSup OBJECT-TYPE`

SYNTAX INTEGER {

 noHprSupport(1),
 hprBaseOnly(2),
 rtpTower(3),
 controlFlowsOverRtpTower(4)
}

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Indicates the level of high performance routing (HPR) support over this link:

`noHprSupport(1) - no HPR support`

hprBaseOnly(2)	- HPR base (option set 1400) supported
rtpTower(3)	- HPR base and RTP tower (option set 1401) supported
controlFlowsOverRtpTower(4)	- HPR base, RTP tower, and control flows over RTP (option set 1402) supported

If the link is not active, the defined value is returned."

```
::= { appnLsEntry 34 }
```

appnLsErrRecoSup OBJECT-TYPE
 SYNTAX TruthValue
 MAX-ACCESS read-only
 STATUS current
 DESCRIPTION
 "Indicates whether the link station is supporting
 HPR link-level error recovery."

```
::= { appnLsEntry 35 }
```

appnLsForAnrLabel OBJECT-TYPE
 SYNTAX OCTET STRING (SIZE (0..8))
 MAX-ACCESS read-only
 STATUS current
 DESCRIPTION
 "The forward Automatic Network Routing (ANR) label for this
 link station. If the link does not support HPR or the value is
 unknown, a zero-length string is returned."

```
::= { appnLsEntry 36 }
```

appnLsRevAnrLabel OBJECT-TYPE
 SYNTAX OCTET STRING (SIZE (0..8))
 MAX-ACCESS read-only
 STATUS current
 DESCRIPTION
 "The reverse Automatic Network Routing (ANR) label for this
 link station. If the link does not support HPR or the value is
 unknown, a zero-length string is returned."

```
::= { appnLsEntry 37 }
```

appnLsCpCpNceId OBJECT-TYPE
 SYNTAX OCTET STRING (SIZE (0..8))
 MAX-ACCESS read-only
 STATUS current

DESCRIPTION

"The network connection endpoint identifier (NCE ID) for CP-CP sessions if this node supports the HPR transport tower, a zero-length string if the value is unknown or not meaningful for this node."

```
::= { appnLsEntry 38 }
```

appnLsRouteNceId OBJECT-TYPE

SYNTAX OCTET STRING (SIZE (0..8))
MAX-ACCESS read-only
STATUS current
DESCRIPTION

"The network connection endpoint identifier (NCE ID) for Route Setup if this node supports the HPR transport tower, a zero-length string if the value is unknown or not meaningful for this node."

```
::= { appnLsEntry 39 }
```

appnLsBfNceId OBJECT-TYPE

SYNTAX OCTET STRING (SIZE (0..8))
MAX-ACCESS read-only
STATUS current
DESCRIPTION

"The network connection endpoint identifier (NCE ID) for the APPN/HPR boundary function if this node supports the HPR transport tower, a zero-length string if the value is unknown or not meaningful for this node."

```
::= { appnLsEntry 40 }
```

appnLsLocalAddr OBJECT-TYPE

SYNTAX DisplayableDlcAddress
MAX-ACCESS read-only
STATUS current
DESCRIPTION

"Local address of this link station."

```
::= { appnLsEntry 41 }
```

appnLsRemoteAddr OBJECT-TYPE

SYNTAX DisplayableDlcAddress
MAX-ACCESS read-only
STATUS current
DESCRIPTION

"Address of the remote link station on this link."

```
 ::= { appnLsEntry 42 }

appnLsRemoteLsName OBJECT-TYPE
    SYNTAX DisplayString (SIZE (0..10))
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "Remote link station discovered from the XID exchange.
        The name can be from one to ten characters. A zero-length
        string indicates that the value is not known."

 ::= { appnLsEntry 43 }

appnLsCounterDisconTime OBJECT-TYPE
    SYNTAX TimeStamp
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "The value of the sysUpTime object the last time the link
        station was started.

 ::= { appnLsEntry 44 }
```

```
*****
-- This table provides information about errors this node encountered
-- with connections to adjacent nodes. Entries are added for exceptional
-- conditions encountered establishing connections and exceptional
-- conditions that resulted in termination of a connection. It is an
-- implementation option how many entries to keep in this table, and
-- how long to retain any individual entry.
*****
```

```
appnLsStatusTable OBJECT-TYPE
    SYNTAX SEQUENCE OF AppnLsStatusEntry
    MAX-ACCESS not-accessible
    STATUS current
    DESCRIPTION
        "This table contains information related to exceptional and
        potentially exceptional conditions that occurred during the
        activation, XID exchange, and termination of a connection. No
        entries are created when these activities proceed normally.

 ::= { appnLinkStationInformation 2 }

appnLsStatusEntry OBJECT-TYPE
    SYNTAX AppnLsStatusEntry
```

```

MAX-ACCESS not-accessible
STATUS current
DESCRIPTION
  "This table is indexed by the LsStatusIndex, which is an
  integer that is continuously updated until it eventually
  wraps."

INDEX
  { appnLsStatusIndex }

 ::= { appnLsStatusTable 1 }

AppnLsStatusEntry ::= SEQUENCE {
  appnLsStatusIndex          INTEGER,
  appnLsStatusTime           DateAndTime,
  appnLsStatusLsName         DisplayString,
  appnLsStatusCpName         DisplayString,
  appnLsStatusPartnerId      SnaNodeIdentification,
  appnLsStatusTgNum          INTEGER,
  appnLsStatusGeneralSense   SnaSenseData,
  appnLsStatusRetry          TruthValue,
  appnLsStatusEndSense       SnaSenseData,
  appnLsStatusXidLocalSense  SnaSenseData,
  appnLsStatusXidRemoteSense SnaSenseData,
  appnLsStatusXidByteInError INTEGER,
  appnLsStatusXidBitInError  INTEGER,
  appnLsStatusDlcType        IANAifType,
  appnLsStatusLocalAddr      DisplayableDlcAddress,
  appnLsStatusRemoteAddr     DisplayableDlcAddress
}

appnLsStatusIndex OBJECT-TYPE
  SYNTAX INTEGER (0..2147483647)
  MAX-ACCESS not-accessible
  STATUS current
  DESCRIPTION
    "Table index. The value of the index begins at zero
    and is incremented up to a maximum value of 2**31-1
    (2,147,483,647) before wrapping."
  ::= { appnLsStatusEntry 1 }

appnLsStatusTime OBJECT-TYPE
  SYNTAX DateAndTime
  MAX-ACCESS read-only
  STATUS current
  DESCRIPTION

```

"Time when the exception condition occurred. This time can be used to identify when this event occurred in relation to other events in the APPN node, for example, the time at which an APPC session was either terminated or failed to be established. This latter time is available in the appcHistSessTime object in the APPC MIB."

```
::= { appnLsStatusEntry 2 }
```

appnLsStatusLsName OBJECT-TYPE
 SYNTAX DisplayString (SIZE (1..10))
 MAX-ACCESS read-only
 STATUS current
 DESCRIPTION
 "Administratively assigned name for the link station experiencing the condition."

```
::= { appnLsStatusEntry 3 }
```

appnLsStatusCpName OBJECT-TYPE
 SYNTAX DisplayString (SIZE (0 | 3..17))
 MAX-ACCESS read-only
 STATUS current
 DESCRIPTION
 "Fully qualified name of the adjacent node for this link station. An adjacent node is identified using the format specified in the SnaControlPointName textual convention."

The value of this object is determined as follows:

1. If the adjacent node's name was received on XID, it is returned.
2. If the adjacent node's name was not received on XID, but a locally-defined value is available, it is returned.
3. Otherwise a string of length 0 is returned, indicating that no name is known for the adjacent node."

```
::= { appnLsStatusEntry 4 }
```

appnLsStatusPartnerId OBJECT-TYPE
 SYNTAX SnaNodeIdentification
 MAX-ACCESS read-only
 STATUS current
 DESCRIPTION
 "The partner's Node Identification, from bytes 2-5 of the XID

received from the partner. If this value is not available, then the characters '00000000' are returned."

::= { appnLsStatusEntry 5 }

appnLsStatusTgNum OBJECT-TYPE
SYNTAX INTEGER (0..256)
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"Number associated with the TG to this link station, with a range from 0 to 256. A value of 256 indicates that the TG number was unknown at the time of the failure."

::= { appnLsStatusEntry 6 }

appnLsStatusGeneralSense OBJECT-TYPE
SYNTAX SnaSenseData
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"The error sense data associated with the start sequence of activation of a link up to the beginning of the XID sequence.

This is the sense data that came from Configuration Services whenever the link did not activate or when it went inactive."

::= { appnLsStatusEntry 7 }

appnLsStatusRetry OBJECT-TYPE
SYNTAX TruthValue
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"Indicates whether the node will retry the start request to activate the link."

::= { appnLsStatusEntry 8 }

appnLsStatusEndSense OBJECT-TYPE
SYNTAX SnaSenseData
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"The sense data associated with the termination of the link connection to adjacent node.

This is the sense data that came from the DLC layer."

```
::= { appnLsStatusEntry 9 }
```

appnLsStatusXidLocalSense OBJECT-TYPE

SYNTAX SnaSenseData

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The sense data associated with the rejection of the XID.

This is the sense data that came from the local node (this node) when it built the XID Negotiation Error control vector (cv22) to send to the remote node."

```
::= { appnLsStatusEntry 10 }
```

appnLsStatusXidRemoteSense OBJECT-TYPE

SYNTAX SnaSenseData

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The sense data the adjacent node returned to this node indicating the reason the XID was rejected.

This is the sense data that came from the remote node in the XID Negotiation Error control vector (cv22) it sent to the local node (this node)."

```
::= { appnLsStatusEntry 11 }
```

appnLsStatusXidByteInError OBJECT-TYPE

SYNTAX INTEGER (0..65536)

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"This object identifies the actual byte in the XID that caused the error. The value 65536 indicates that the object has no meaning.

For values in the range 0-65535, this object corresponds to bytes 2-3 of the XID Negotiation (X'22') control vector."

```
::= { appnLsStatusEntry 12 }
```

appnLsStatusXidBitInError OBJECT-TYPE

SYNTAX INTEGER (0..8)

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"This object identifies the actual bit in error (0 through 7) within the errored byte of the XID. The value 8 indicates that this object has no meaning.

For values in the range 0-7, this object corresponds to byte 4 of the XID Negotiation (X'22') control vector."

::= { appnLsStatusEntry 13 }

appnLsStatusDlcType OBJECT-TYPE
SYNTAX IANAifType
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"The type of DLC interface, distinguished according to the protocol immediately 'below' this layer."

::= { appnLsStatusEntry 14 }

appnLsStatusLocalAddr OBJECT-TYPE
SYNTAX DisplayableDlcAddress
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"Local address of this link station."

::= { appnLsStatusEntry 15 }

appnLsStatusRemoteAddr OBJECT-TYPE
SYNTAX DisplayableDlcAddress
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"Address of the remote link station on this link."

::= { appnLsStatusEntry 16 }

-- *****
-- APPN Virtual Routing Node Information
--

appnVrnTable OBJECT-TYPE
SYNTAX SEQUENCE OF AppnVrnEntry
MAX-ACCESS not-accessible
STATUS current
DESCRIPTION
"This table relates a virtual routing node to an APPN port."

```
::= { appnVrnInfo 1 }

appnVrnEntry OBJECT-TYPE
    SYNTAX AppnVrnEntry
    MAX-ACCESS not-accessible
    STATUS current
    DESCRIPTION
        "This table is indexed by the virtual routing node name, TG
         number, and port name. There will be a matching entry in the
         appnLocalTgTable to represent status and characteristics of the
         TG representing each virtual routing node definition."

INDEX
    { appnVrnName, appnVrnTgNum, appnVrnPortName }

 ::= { appnVrnTable 1 }

AppnVrnEntry ::= SEQUENCE {
    appnVrnName            SnaControlPointName,
    appnVrnTgNum           INTEGER,
    appnVrnPortName        DisplayString
}

appnVrnName OBJECT-TYPE
    SYNTAX SnaControlPointName
    MAX-ACCESS not-accessible
    STATUS current
    DESCRIPTION
        "Administratively assigned name of the virtual routing node.
         This is a fully qualified name, and matches the appnLocalTgDest
         name in the appnLocalTgTable."

 ::= { appnVrnEntry 1 }

appnVrnTgNum OBJECT-TYPE
    SYNTAX INTEGER (0..255)
    MAX-ACCESS not-accessible
    STATUS current
    DESCRIPTION
        "Number associated with the transmission group representing
         this virtual routing node definition."

 ::= { appnVrnEntry 2 }

appnVrnPortName OBJECT-TYPE
    SYNTAX DisplayString (SIZE (1..10))
    MAX-ACCESS read-only
    STATUS current
```

DESCRIPTION

"The name of the port this virtual routing node definition is defined to."

::= { appnVrnEntry 3 }

-- ***** The APPN Topology Group *****

appnNn OBJECT IDENTIFIER ::= { appnObjects 2 }
appnNnTopo OBJECT IDENTIFIER ::= { appnNn 1 }
appnNnTopology OBJECT IDENTIFIER ::= { appnNn 2 }

-- This group is used to represent the entire APPN network-node topology
-- including network nodes, virtual routing nodes and all TGs associated
-- with these nodes.

--

-- Network nodes

-- The APPN topology database consists of information about every APPN
-- network node in this network node's topology subnetwork. This
-- information is learned over time as each network node exchanges
-- topology information with the network nodes adjacent to it. The
-- database consists of information about each node, and information
-- about all of the transmission groups used by these nodes.

--

-- Virtual routing nodes

-- Information about virtual routing nodes (representing connection
-- networks) is treated in the same way as information about network
-- nodes, and is replicated at each network node. The FRSN, node name,
-- and node type are the only meaningful fields for a virtual routing
-- node. The other node objects return unspecified values. Each
-- node that has defined a TG with this virtual routing node as the
-- destination also defines a TG on this virtual routing node. There
-- is a TG record for each node that uses this virtual routing node.

--

-- The APPN node table represents node information from the APPN topology
-- database, with the FRSN and APPN CP fully qualified name serving as
-- the index. The FRSN is the agent's relative time stamp of an update
-- to the network topology database. After collecting the entire database
-- once, a management application can issue GET NEXT commands starting
-- from the last rows it has retrieved from the appnNnTopologyFRTTable and
-- from the appnNnTgTopologyFRTTable. When the response to either of these
-- GET NEXT commands returns another row of its respective table, this
-- indicates a change to the agent's topology database. The management
-- application can then retrieve only the updates to the table, using
-- GET NEXT commands starting from the last retrieved node or TG
-- entry.

--

-- The format of the actual APPN topology database is as follows:

```
--  
-- Node table (entry for each node in network)  
-- TG table (entry for each TG owned by node)  
--  
-- Due to SNMP's ASN.1 limitations, we cannot represent the TG table  
-- within the node table in this way. We define separate tables for  
-- nodes and TGs, adding the node name to each TG entry to provide a  
-- means of correlating the TG with its originating node.  
  
appnNnTopoMaxNodes OBJECT-TYPE  
    SYNTAX Gauge32  
    UNITS "node entries"  
    MAX-ACCESS read-only  
    STATUS current  
    DESCRIPTION  
        "Maximum number of node entries allowed in the APPN topology  
        database. It is an implementation choice whether to count only  
        network-node entries, or to count all node entries. If the  
        number of node entries exceeds this value, APPN will issue an  
        Alert and the node can no longer participate as a network node.  
        The value 0 indicates that the local node has no defined limit,  
        and the number of node entries is bounded only by memory."  
  
 ::= { appnNnTopo 1 }  
  
appnNnTopoCurNumNodes OBJECT-TYPE  
    SYNTAX Gauge32  
    UNITS "node entries"  
    MAX-ACCESS read-only  
    STATUS current  
    DESCRIPTION  
        "Current number of node entries in this node's topology  
        database. It is an implementation choice whether to count only  
        network-node entries, or to count all node entries, but an  
        implementation must make the same choice here that it makes for  
        the appnNnTopoMaxNodes object. If this value exceeds the  
        maximum number of nodes allowed (appnNnTopoMaxNodes, if that  
        field is not 0), APPN Alert CPDB002 is issued."  
  
 ::= { appnNnTopo 2 }  
  
appnNnTopoNodePurges OBJECT-TYPE  
    SYNTAX AppnNodeCounter  
    UNITS "node entries"  
    MAX-ACCESS read-only  
    STATUS current  
    DESCRIPTION  
        "Total number of topology node records purged from this node's
```

```
topology database since the node was last re-initialized."  
 ::= { appnNnTopo 3 }  
  
appnNnTopoTgPurges OBJECT-TYPE  
  SYNTAX AppnNodeCounter  
  UNITS "TG entries"  
  MAX-ACCESS read-only  
  STATUS current  
  DESCRIPTION  
    "Total number of topology TG records purged from this node's  
     topology database since the node was last re-initialized."  
 ::= { appnNnTopo 4 }  
  
appnNnTopoTotalTduWars OBJECT-TYPE  
  SYNTAX AppnNodeCounter  
  UNITS "TDU wars"  
  MAX-ACCESS read-only  
  STATUS current  
  DESCRIPTION  
    "Number of TDU wars detected by this node since its last  
     initialization."  
 ::= { appnNnTopo 5 }  
  
-- APPN network node topology table (using FRSN and name as index)  
-- This table describes every APPN network node and virtual routing node  
-- represented in this node's topology database.  
  
appnNnTopologyFRTTable OBJECT-TYPE  
  SYNTAX SEQUENCE OF AppnNnTopologyFREntry  
  MAX-ACCESS not-accessible  
  STATUS current  
  DESCRIPTION  
    "Portion of the APPN topology database that describes all of  
     the APPN network nodes and virtual routing nodes known to this  
     node."  
 ::= { appnNnTopology 3 }  
  
appnNnTopologyFREntry OBJECT-TYPE  
  SYNTAX AppnNnTopologyFREntry  
  MAX-ACCESS not-accessible  
  STATUS current
```

DESCRIPTION

"The FRSN and the fully qualified node name are used to index this table."

INDEX

```
{appnNnNodeFRFrsn,
 appnNnNodeFRName}
```

```
::= { appnNnTopologyFRTTable 1 }
```

```
AppnNnTopologyFREntry ::= SEQUENCE {
    appnNnNodeFRFrsn                      Unsigned32,
    appnNnNodeFRName                       SnaControlPointName,
    appnNnNodeFREntryTimeLeft              AppnTopologyEntryTimeLeft,
    appnNnNodeFRType                        INTEGER,
    appnNnNodeFRRsn                        Unsigned32,
    appnNnNodeFRRouteAddResist            INTEGER,
    appnNnNodeFRCongested                 TruthValue,
    appnNnNodeFRIIsrDepleted              TruthValue,
    appnNnNodeFRQuiescing                 TruthValue,
    appnNnNodeFRGateway                  TruthValue,
    appnNnNodeFRCentralDirectory         TruthValue,
    appnNnNodeFRIIsr                     TruthValue,
    appnNnNodeFRGarbageCollect           TruthValue,
    appnNnNodeFRHprSupport                INTEGER,
    appnNnNodeFRPeriBorderSup             TruthValue,
    appnNnNodeFRInterchangeSup           TruthValue,
    appnNnNodeFRExteBorderSup            TruthValue
}
```

appnNnNodeFRFrsn OBJECT-TYPE

SYNTAX Unsigned32
 MAX-ACCESS not-accessible
 STATUS current

DESCRIPTION

"Flow reduction sequence numbers (FRSNs) are associated with Topology Database Updates (TDUs) and are unique only within each APPN network node. A TDU can be associated with multiple APPN resources. This FRSN indicates the last relative time this resource was updated at the agent node."

```
::= { appnNnTopologyFREntry 1 }
```

```
appnNnNodeFRName OBJECT-TYPE
  SYNTAX SnaControlPointName
  MAX-ACCESS not-accessible
```

```
STATUS current
DESCRIPTION
  "Administratively assigned network name that is locally defined
  at each network node."
 ::= { appnNnTopologyFREntry 2 }

appnNnNodeFREntryTimeLeft OBJECT-TYPE
  SYNTAX AppnTopologyEntryTimeLeft
  UNITS "days"
  MAX-ACCESS read-only
  STATUS current
  DESCRIPTION
    "Number of days before deletion of this network node entry."
 ::= { appnNnTopologyFREntry 3 }

appnNnNodeFRType OBJECT-TYPE
  SYNTAX INTEGER {
    networkNode(1),
    virtualRoutingNode(3)
  }
  MAX-ACCESS read-only
  STATUS current
  DESCRIPTION
    "Type of APPN node."
 ::= { appnNnTopologyFREntry 4 }

appnNnNodeFRRsn OBJECT-TYPE
  SYNTAX Unsigned32
  MAX-ACCESS read-only
  STATUS current
  DESCRIPTION
    "Resource sequence number, which is assigned and controlled by
    the network node that owns this resource. An odd number
    indicates that information about the resource is inconsistent.

    This object corresponds to the numeric value in cv4580, bytes
    2-5."
 ::= { appnNnTopologyFREntry 5 }

appnNnNodeFRRouteAddResist OBJECT-TYPE
  SYNTAX INTEGER (0..255)
  MAX-ACCESS read-only
  STATUS current
  DESCRIPTION
```

"Route addition resistance.

This administratively assigned value indicates the relative desirability of using this node for intermediate session traffic. The value, which can be any integer 0-255, is used in route computation. The lower the value, the more desirable the node is for intermediate routing.

This object corresponds to cv4580, byte 6."

`::= { appnNnTopologyFREntry 6 }`

`appnNnNodeFRCongested` OBJECT-TYPE

SYNTAX TruthValue

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Indicates whether this node is congested. This node is not be included in route selection by other nodes when this congestion exists.

This object corresponds to cv4580, byte 7, bit 0."

`::= { appnNnTopologyFREntry 7 }`

`appnNnNodeFRIsrDepleted` OBJECT-TYPE

SYNTAX TruthValue

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Indicates whether intermediate session routing resources are depleted. This node is not included in intermediate route selection by other nodes when resources are depleted.

This object corresponds to cv4580, byte 7, bit 1."

`::= { appnNnTopologyFREntry 8 }`

`appnNnNodeFRQuiescing` OBJECT-TYPE

SYNTAX TruthValue

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Indicates whether the node is quiescing. This node is not included in route selection by other nodes when the node is quiescing.

This object corresponds to cv4580, byte 7, bit 5."

```
 ::= { appnNnTopologyFREntry 9 }

appnNnNodeFRGateway OBJECT-TYPE
    SYNTAX TruthValue
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "Indicates whether the node provide gateway services.

    This object corresponds to cv4580, byte 8, bit 0."


 ::= { appnNnTopologyFREntry 10 }

appnNnNodeFRCentralDirectory OBJECT-TYPE
    SYNTAX TruthValue
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "Indicates whether the node supports central directory
        services.

    This object corresponds to cv4580, byte 8, bit 1."


 ::= { appnNnTopologyFREntry 11 }

appnNnNodeFRIsr OBJECT-TYPE
    SYNTAX TruthValue
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "Indicates whether the node supports intermediate session
        routing (ISR).

    This object corresponds to cv4580, byte 8, bit 2."


 ::= { appnNnTopologyFREntry 12 }

appnNnNodeFRGarbageCollect OBJECT-TYPE
    SYNTAX TruthValue
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "Indicates whether the node has been marked for garbage
        collection (deletion from the topology database) upon the next
        garbage collection cycle.
```

This object corresponds to cv4580, byte 7, bit 3."

```
::= { appnNnTopologyFREntry 13 }
```

appnNnNodeFRHprSupport OBJECT-TYPE

SYNTAX INTEGER {

- noHprSupport(1),
- hprBaseOnly(2),
- rtpTower(3),
- controlFlowsOverRtpTower(4)

}

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Indicates the node's level of support for high-performance routing (HPR):

noHprSupport(1)	- no HPR support
hprBaseOnly(2)	- HPR base (option set 1400) supported
rtpTower(3)	- HPR base and RTP tower (option set 1401) supported
controlFlowsOverRtpTower(4)	- HPR base, RTP tower, and control flows over RTP (option set 1402) supported

This object corresponds to cv4580, byte 9, bits 3-4."

```
::= { appnNnTopologyFREntry 14 }
```

appnNnNodeFRPeriBorderSup OBJECT-TYPE

SYNTAX TruthValue

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Indicates whether this node has peripheral border node support.

This object corresponds to cv4580, byte 9, bit 0."

```
::= { appnNnTopologyFREntry 15 }
```

appnNnNodeFRInterchangeSup OBJECT-TYPE

SYNTAX TruthValue

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Indicates whether this node has interchange node support.

This object corresponds to cv4580, byte 9, bit 1."

::= { appnNnTopologyFREntry 16 }

appnNnNodeFRExteBorderSup OBJECT-TYPE

SYNTAX TruthValue

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Indicates whether this node has extended border node support.

This object corresponds to cv4580, byte 9, bit 2."

::= { appnNnTopologyFREntry 17 }

--APPN transmission group (TG) table

-- This table describes the TGs associated with all the APPN network
-- nodes known to this node. The originating (owning) node for each
-- TG is repeated here to provide a means of correlating the TGs with
-- the nodes.

appnNnTgTopologyFRTTable OBJECT-TYPE

SYNTAX SEQUENCE OF AppnNnTgTopologyFREntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"Portion of the APPN topology database that describes all of the APPN transmissions groups between nodes in the database."

::= { appnNnTopology 4 }

appnNnTgTopologyFREntry OBJECT-TYPE

SYNTAX AppnNnTgTopologyFREntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"This table is indexed by four columns: FRSN, TG owner fully qualified node name, TG destination fully qualified node name, and TG number."

INDEX

{appnNnTgFRFrsn,
 appnNnTgFROwner,
 appnNnTgFRDest,

```

    appnNnTgFRNum}

 ::= { appnNnTgTopologyFRTTable 1 }

AppnNnTgTopologyFREntry ::= SEQUENCE {
    appnNnTgFRFrsn          Unsigned32,
    appnNnTgFROwner          SnaControlPointName,
    appnNnTgFRDest           SnaControlPointName,
    appnNnTgFRNum             INTEGER,
    appnNnTgFREntryTimeLeft  AppnTopologyEntryTimeLeft,
    appnNnTgFRDestVirtual    TruthValue,
    appnNnTgFRDlcData        AppnTgDlcData,
    appnNnTgFRRsn            Unsigned32,
    appnNnTgFROperational    TruthValue,
    appnNnTgFRQuiescing      TruthValue,
    appnNnTgFRCpCpSession    INTEGER,
    appnNnTgFREffCap         AppnTgEffectiveCapacity,
    appnNnTgFRConnCost       INTEGER,
    appnNnTgFRByteCost       INTEGER,
    appnNnTgFRSecurity       AppnTgSecurity,
    appnNnTgFRDelay          AppnTgDelay,
    appnNnTgFRUsr1            INTEGER,
    appnNnTgFRUsr2            INTEGER,
    appnNnTgFRUsr3            INTEGER,
    appnNnTgFRGarbageCollect TruthValue,
    appnNnTgFRSubareaNum     Unsigned32,
    appnNnTgFRHprSup          TruthValue,
    appnNnTgFRDestHprTrans   TruthValue,
    appnNnTgFRTypeIndicator  INTEGER,
    appnNnTgFRIintersubnet   TruthValue
}

```

```

appnNnTgFRFrsn OBJECT-TYPE
    SYNTAX Unsigned32
    MAX-ACCESS not-accessible
    STATUS current
    DESCRIPTION
        "Flow reduction sequence numbers (FRSNs) are associated with
        Topology Database Updates (TDUs) and are unique only within
        each APPN network node. A TDU can be associated with multiple
        APPN resources. This FRSN indicates the last time this
        resource was updated at this node."

```

```
 ::= { appnNnTgTopologyFREntry 1 }

appnNnTgFROwner OBJECT-TYPE
    SYNTAX SnaControlPointName
    MAX-ACCESS not-accessible
    STATUS current
    DESCRIPTION
        "Administratively assigned name for the originating node for
         this TG. This is the same name specified in the node table."

 ::= { appnNnTgTopologyFREntry 2 }

appnNnTgFRDest OBJECT-TYPE
    SYNTAX SnaControlPointName
    MAX-ACCESS not-accessible
    STATUS current
    DESCRIPTION
        "Administratively assigned fully qualified network name for the
         destination node for this TG."

 ::= { appnNnTgTopologyFREntry 3 }

appnNnTgFRNum OBJECT-TYPE
    SYNTAX INTEGER (0..255)
    MAX-ACCESS not-accessible
    STATUS current
    DESCRIPTION
        "Number associated with this transmission group. Range is
         0-255."

 ::= { appnNnTgTopologyFREntry 4 }

appnNnTgFREntryTimeLeft OBJECT-TYPE
    SYNTAX AppnTopologyEntryTimeLeft
    UNITS "days"
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "Number of days before deletion of this network node TG entry
         if it is not operational or has an odd (inconsistent) RSN."

 ::= { appnNnTgTopologyFREntry 5 }

appnNnTgFRDestVirtual OBJECT-TYPE
    SYNTAX TruthValue
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
```

"Indicates whether the destination node is a virtual routing node."

`::= { appnNnTgTopologyFREntry 6 }`

`appnNnTgFRDlcData OBJECT-TYPE`

SYNTAX AppnTgDlcData

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"DLC-specific data related to a link connection network."

`::= { appnNnTgTopologyFREntry 7 }`

`appnNnTgFRRsn OBJECT-TYPE`

SYNTAX Unsigned32

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Current owning node's resource sequence number for this resource. An odd number indicates that information about the resource is inconsistent.

This object corresponds to the numeric value in cv47, bytes 2-5"

`::= { appnNnTgTopologyFREntry 8 }`

`appnNnTgFROperational OBJECT-TYPE`

SYNTAX TruthValue

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Indicates whether the transmission group is operational.

This object corresponds to cv47, byte 6, bit 0."

`::= { appnNnTgTopologyFREntry 9 }`

`appnNnTgFRQuiescing OBJECT-TYPE`

SYNTAX TruthValue

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Indicates whether the transmission group is quiescing.

This object corresponds to cv47, byte 6, bit 2."

```

 ::= { appnNnTgTopologyFREntry 10 }

appnNnTgFRCpCpSession OBJECT-TYPE
  SYNTAX INTEGER {
    supportedUnknownStatus(1),
    supportedActive(2),
    notSupported(3),
    supportedNotActive(4)
  }
  MAX-ACCESS read-only
  STATUS current
  DESCRIPTION
    "Indicates whether CP-CP sessions are supported on this TG, and
     whether the TG owner's contention-winner session is active on
     this TG. Some nodes in the network are not able to
     differentiate support and status of CP-CP sessions, and thus
     may report the 'supportedUnknownStatus' value.

This object corresponds to cv47, byte 6, bits 3-4."


 ::= { appnNnTgTopologyFREntry 11 }

appnNnTgFREffCap OBJECT-TYPE
  SYNTAX AppnTgEffectiveCapacity
  MAX-ACCESS read-only
  STATUS current
  DESCRIPTION
    "Effective capacity for this TG."


 ::= { appnNnTgTopologyFREntry 12 }

appnNnTgFRCConnCost OBJECT-TYPE
  SYNTAX INTEGER (0..255)
  MAX-ACCESS read-only
  STATUS current
  DESCRIPTION
    "Cost per connect time.

This is an administratively assigned value representing the
relative cost per unit of time to use this TG. Range is from
0, which means no cost, to 255, which indicates maximum cost.

This object corresponds to cv47, byte 13."


 ::= { appnNnTgTopologyFREntry 13 }

appnNnTgFRByteCost OBJECT-TYPE

```

```
SYNTAX INTEGER (0..255)
MAX-ACCESS read-only
STATUS current
DESCRIPTION
    "Cost per byte transmitted.
```

This is an administratively assigned value representing the relative cost of transmitting a byte over this TG. Range is from 0, which means no cost, to 255, which indicates maximum cost.

This object corresponds to cv47, byte 14."

```
::= { appnNnTgTopologyFREntry 14 }
```

```
appnNnTgFRSecurity OBJECT-TYPE
    SYNTAX AppnTgSecurity
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "Administratively assigned security level of this TG.
```

This object corresponds to cv47, byte 16."

```
::= { appnNnTgTopologyFREntry 15 }
```

```
appnNnTgFRDelay OBJECT-TYPE
    SYNTAX AppnTgDelay
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "Administratively assigned delay associated with this TG.
```

This object corresponds to cv47, byte 17."

```
::= { appnNnTgTopologyFREntry 16 }
```

```
appnNnTgFRUsrl OBJECT-TYPE
    SYNTAX INTEGER (0..255)
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "First user-defined TG characteristic for this TG. This is
         an administratively assigned value associated with the TG.
```

This object corresponds to cv47, byte 19."

```
::= { appnNnTgTopologyFREntry 17 }
```

```
appnNnTgFRUsr2 OBJECT-TYPE
    SYNTAX INTEGER (0..255)
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "Second user-defined TG characteristic for this TG. This is
         an administratively assigned value associated with the TG.
```

This object corresponds to cv47, byte 20."

```
::= { appnNnTgTopologyFREntry 18 }
```

```
appnNnTgFRUsr3 OBJECT-TYPE
    SYNTAX INTEGER (0..255)
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "Third user-defined TG characteristic for this TG. This is
         an administratively assigned value associated with the TG.
```

This object corresponds to cv47, byte 21."

```
::= { appnNnTgTopologyFREntry 19 }
```

```
appnNnTgFRGarbageCollect OBJECT-TYPE
    SYNTAX TruthValue
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "Indicates whether the TG has been marked for garbage
         collection (deletion from the topology database) upon the next
         garbage collection cycle.
```

This object corresponds to cv47, byte 6, bit 1."

```
::= { appnNnTgTopologyFREntry 20 }
```

```
appnNnTgFRSubareaNum OBJECT-TYPE
    SYNTAX Unsigned32
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "The subarea number associated with this TG.
```

This object corresponds to cv4680, bytes m+2 through m+5."

```
::= { appnNnTgTopologyFREntry 21 }
```

```
appnNnTgFRHprSup OBJECT-TYPE
    SYNTAX TruthValue
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "Indicates whether high performance routing (HPR)
         is supported over this TG."
```

This object corresponds to cv4680, byte m+1, bit 2."

```
::= { appnNnTgTopologyFREntry 22 }
```

```
appnNnTgFRDestHprTrans OBJECT-TYPE
    SYNTAX TruthValue
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "Indicates whether the destination node supports
         high performance routing (HPR) transport tower."
```

This object corresponds to cv4680, byte m+1, bit 7."

```
::= { appnNnTgTopologyFREntry 23 }
```

```
appnNnTgFRTyPeIndicator OBJECT-TYPE
    SYNTAX INTEGER {
        unknown(1),
        appnOrBftTg(2),
        interchangeTg(3),
        virtualRouteTg(4)
    }
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "Indicates the type of the TG."
```

This object corresponds to cv4680, byte m+1, bits 3-4."

```
::= { appnNnTgTopologyFREntry 24 }
```

```
appnNnTgFRIintersubnet OBJECT-TYPE
    SYNTAX TruthValue
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "Indicates whether the transmission group is an intersubnet TG,
         which defines a border between subnetworks."
```

```
This object corresponds to cv4680, byte m+1, bit 5."  
 ::= { appnNnTgTopologyFREntry 25 }  
  
-- ***** The APPN Local Topology Group *****  
-- This MIB Group represents the local topology maintained in  
-- both APPN end nodes and network nodes. It consists of two  
-- tables:  
-- - a table containing information about all of the TGs owned  
-- by this node, which is implemented by all node types.  
-- - a table containing all of the information known to this node  
-- about the TGs owned by its end nodes, which is implemented only  
-- by network nodes.  
  
appnLocalTopology OBJECT IDENTIFIER ::= { appnObjects 3 }  
  
-- APPN Local Transmission Group (TG) table  
-- This table describes the TGs associated with this node only.  
  
appnLocalTgTable OBJECT-TYPE  
    SYNTAX SEQUENCE OF AppnLocalTgEntry  
    MAX-ACCESS not-accessible  
    STATUS current  
    DESCRIPTION  
        "TG Table describes all of the TGs owned by this node. The TG  
        destination can be a virtual node, network node, LEN node, or  
        end node."  
    ::= { appnLocalTopology 1 }  
  
appnLocalTgEntry OBJECT-TYPE  
    SYNTAX AppnLocalTgEntry  
    MAX-ACCESS not-accessible  
    STATUS current  
    DESCRIPTION  
        "This table is indexed by the destination CPname and the TG  
        number."  
    INDEX  
        { appnLocalTgDest,  
          appnLocalTgNum }  
    ::= { appnLocalTgTable 1 }  
  
AppnLocalTgEntry ::= SEQUENCE {  
    appnLocalTgDest            SnaControlPointName,  
    appnLocalTgNum             INTEGER,
```

```

appnLocalTgDestVirtual  TruthValue,
appnLocalTgDlcData      AppnTgDlcData,
appnLocalTgPortName     DisplayString,

appnLocalTgQuiescing   TruthValue,
appnLocalTgOperational  TruthValue,
appnLocalTgCpCpSession  INTEGER,
appnLocalTgEffCap      AppnTgEffectiveCapacity,
appnLocalTgConnCost    INTEGER,
appnLocalTgByteCost    INTEGER,
appnLocalTgSecurity    AppnTgSecurity,
appnLocalTgDelay       AppnTgDelay,
appnLocalTgUsr1         INTEGER,
appnLocalTgUsr2         INTEGER,
appnLocalTgUsr3         INTEGER,

appnLocalTgHprSup      INTEGER,
appnLocalTgIntersubnet  TruthValue
}

appnLocalTgDest OBJECT-TYPE
  SYNTAX SnaControlPointName
  MAX-ACCESS not-accessible
  STATUS current
  DESCRIPTION
    "Administratively assigned name of the destination node for
     this TG. This is the fully qualified name of a network node,
     end node, LEN node, or virtual routing node."
  ::= { appnLocalTgEntry 1 }

appnLocalTgNum OBJECT-TYPE
  SYNTAX INTEGER (0..255)
  MAX-ACCESS not-accessible
  STATUS current
  DESCRIPTION
    "Number associated with this transmission group."
  ::= { appnLocalTgEntry 2 }

appnLocalTgDestVirtual OBJECT-TYPE
  SYNTAX TruthValue
  MAX-ACCESS read-only
  STATUS current
  DESCRIPTION
    "Indicates whether the destination node for this TG is a
     virtual routing node."

```

```
 ::= { appnLocalTgEntry 3 }

appnLocalTgDlcData OBJECT-TYPE
    SYNTAX AppnTgDlcData
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "DLC-specific data related to a link connection network."

 ::= { appnLocalTgEntry 4 }

appnLocalTgPortName OBJECT-TYPE
    SYNTAX DisplayString (SIZE (0..10))
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "Administratively assigned name for the local port associated
         with this TG. A zero-length string indicates that this value
         is unknown."

 ::= { appnLocalTgEntry 5 }

appnLocalTgQuiescing OBJECT-TYPE
    SYNTAX TruthValue
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "Indicates whether the transmission group is quiescing."

 ::= { appnLocalTgEntry 6 }

appnLocalTgOperational OBJECT-TYPE
    SYNTAX TruthValue
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "Indicates whether the transmission group is operational."

 ::= { appnLocalTgEntry 7 }

appnLocalTgCpCpSession OBJECT-TYPE
    SYNTAX INTEGER {
        supportedUnknownStatus(1),
        supportedActive(2),
        notSupported(3),
        supportedNotActive(4)
    }
    MAX-ACCESS read-only
```

```
STATUS current
DESCRIPTION
  "Indicates whether CP-CP sessions are supported on this TG, and
  whether the TG owner's contention-winner session is active on
  this TG. Some nodes in the network are not able to
  differentiate support and status of CP-CP sessions, and thus
  may report the 'supportedUnknownStatus' value."
 ::= { appnLocalTgEntry 8 }

appnLocalTgEffCap OBJECT-TYPE
  SYNTAX AppnTgEffectiveCapacity
  MAX-ACCESS read-only
  STATUS current
  DESCRIPTION
    "Effective capacity for this TG."
 ::= { appnLocalTgEntry 9 }

appnLocalTgConnCost OBJECT-TYPE
  SYNTAX INTEGER (0..255)
  MAX-ACCESS read-only
  STATUS current
  DESCRIPTION
    "Cost per connect time: a value representing the relative cost
    per unit of time to use the TG. Range is from 0, which means
    no cost, to 255."
 ::= { appnLocalTgEntry 10 }

appnLocalTgByteCost OBJECT-TYPE
  SYNTAX INTEGER (0..255)
  MAX-ACCESS read-only
  STATUS current
  DESCRIPTION
    "Relative cost of transmitting a byte over this link.
    Range is from 0 (lowest cost) to 255."
 ::= { appnLocalTgEntry 11 }

appnLocalTgSecurity OBJECT-TYPE
  SYNTAX AppnTgSecurity
  MAX-ACCESS read-only
  STATUS current
  DESCRIPTION
    "Administratively assigned security level of this TG."
 ::= { appnLocalTgEntry 12 }
```

```
appnLocalTgDelay OBJECT-TYPE
    SYNTAX AppnTgDelay
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "Administratively assigned delay associated with this TG."
    ::= { appnLocalTgEntry 13 }

appnLocalTgUsr1 OBJECT-TYPE
    SYNTAX INTEGER (0..255)
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "First user-defined TG characteristic for this TG. This is
         an administratively assigned value associated with the TG."
    ::= { appnLocalTgEntry 14 }

appnLocalTgUsr2 OBJECT-TYPE
    SYNTAX INTEGER (0..255)
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "Second user-defined TG characteristic for this TG. This is
         an administratively assigned value associated with the TG."
    ::= { appnLocalTgEntry 15 }

appnLocalTgUsr3 OBJECT-TYPE
    SYNTAX INTEGER (0..255)
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "Third user-defined TG characteristic for this TG. This is
         an administratively assigned value associated with the TG."
    ::= { appnLocalTgEntry 16 }

appnLocalTgHprSup OBJECT-TYPE
    SYNTAX INTEGER {
        noHprSupport(1),
        hprBaseOnly(2),
        rtpTower(3),
        controlFlowsOverRtpTower(4)
    }
    MAX-ACCESS read-only
    STATUS current
```

DESCRIPTION

"Indicates the level of high performance routing (HPR) support over this TG :

noHprSupport(1)	- no HPR support
hprBaseOnly(2)	- HPR base (option set 1400) supported
rtpTower(3)	- HPR base and RTP tower (option set 1401) supported
controlFlowsOverRtpTower(4)	- HPR base, RTP tower, and control flows over RTP (option set 1402) supported"

::= { appnLocalTgEntry 17 }

appnLocalTgIntersubnet OBJECT-TYPE

SYNTAX TruthValue

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Indicates whether the transmission group is an intersubnet TG, which defines a border between subnetworks."

::= { appnLocalTgEntry 18 }

-- APPN Local End Node Transmission Group (TG) table

-- This table describes the TGs associated with all of the end nodes

-- known to this node.

appnLocalEnTgTable OBJECT-TYPE

SYNTAX SEQUENCE OF AppnLocalEnTgEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"Table describing all of the TGs owned by the end nodes known to this node via TG registration. This node does not represent its own view of the TG on behalf of the partner node in this table. The TG destination can be a virtual routing node, network node, or end node."

::= { appnLocalTopology 2 }

appnLocalEnTgEntry OBJECT-TYPE

SYNTAX AppnLocalEnTgEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"This table requires multiple indexes to uniquely identify each TG. They are originating CPname, destination CPname, and the TG number."

INDEX

```
{appnLocalEnTgOrigin,
 appnLocalEnTgDest,
 appnLocalEnTgNum}
```

```
::= { appnLocalEnTgTable 1 }
```

```
AppnLocalEnTgEntry ::= SEQUENCE {
    appnLocalEnTgOrigin          SnaControlPointName,
    appnLocalEnTgDest            SnaControlPointName,
    appnLocalEnTgNum             INTEGER,
    appnLocalEnTgEntryTimeLeft  AppnTopologyEntryTimeLeft,
    appnLocalEnTgDestVirtual     TruthValue,
    appnLocalEnTgDlcData         AppnTgDlcData,
    appnLocalEnTgOperational     TruthValue,
    appnLocalEnTgCpCpSession     INTEGER,
    appnLocalEnTgEffCap          AppnTgEffectiveCapacity,
    appnLocalEnTgConnCost        INTEGER,
    appnLocalEnTgByteCost        INTEGER,
    appnLocalEnTgSecurity        AppnTgSecurity,
    appnLocalEnTgDelay           AppnTgDelay,
    appnLocalEnTgUsr1             INTEGER,
    appnLocalEnTgUsr2             INTEGER,
    appnLocalEnTgUsr3             INTEGER
}
```

```
appnLocalEnTgOrigin OBJECT-TYPE
    SYNTAX SnaControlPointName
    MAX-ACCESS not-accessible
    STATUS current
    DESCRIPTION
        "Administratively assigned name of the origin node for this
         TG. This is a fully qualified network name."
```

```
::= { appnLocalEnTgEntry 1 }
```

```
appnLocalEnTgDest OBJECT-TYPE
    SYNTAX SnaControlPointName
    MAX-ACCESS not-accessible
    STATUS current
    DESCRIPTION
        "Administratively assigned name of the destination node for"
```

this TG. This is the fully qualified name of a network node, end node, LEN node, or virtual routing node."

::= { appnLocalEnTgEntry 2 }

appnLocalEnTgNum OBJECT-TYPE
SYNTAX INTEGER (0..255)
MAX-ACCESS not-accessible
STATUS current
DESCRIPTION
"Number associated with this transmission group."

::= { appnLocalEnTgEntry 3 }

appnLocalEnTgEntryTimeLeft OBJECT-TYPE
SYNTAX AppnTopologyEntryTimeLeft
UNITS "days"
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"Number of days before deletion of this end node TG entry."

::= { appnLocalEnTgEntry 4 }

appnLocalEnTgDestVirtual OBJECT-TYPE
SYNTAX TruthValue
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"Indicates whether the destination node is a virtual routing node."

::= { appnLocalEnTgEntry 5 }

appnLocalEnTgDlcData OBJECT-TYPE
SYNTAX AppnTgDlcData
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"DLC-specific data related to a link connection network."

::= { appnLocalEnTgEntry 6 }

appnLocalEnTgOperational OBJECT-TYPE
SYNTAX TruthValue
MAX-ACCESS read-only
STATUS current
DESCRIPTION

"Indicates whether the transmission group is operational."

`::= { appnLocalEnTgEntry 7 }`

`appnLocalEnTgCpCpSession` OBJECT-TYPE

SYNTAX INTEGER {
 supportedUnknownStatus(1),
 supportedActive(2),
 notSupported(3),
 supportedNotActive(4)
}

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Indicates whether CP-CP sessions are supported on this TG, and whether the TG owner's contention-winner session is active on this TG. Some nodes in the network are not able to differentiate support and status of CP-CP sessions, and thus may report the 'supportedUnknownStatus' value."

`::= { appnLocalEnTgEntry 8 }`

`appnLocalEnTgEffCap` OBJECT-TYPE

SYNTAX AppnTgEffectiveCapacity

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Effective capacity for this TG."

`::= { appnLocalEnTgEntry 9 }`

`appnLocalEnTgConnCost` OBJECT-TYPE

SYNTAX INTEGER (0..255)

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Cost per connect time: a value representing the relative cost per unit of time to use the TG. Range is from 0, which means no cost, to 255."

`::= { appnLocalEnTgEntry 10 }`

`appnLocalEnTgByteCost` OBJECT-TYPE

SYNTAX INTEGER (0..255)

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Relative cost of transmitting a byte over this link.

Range is from 0, which means no cost, to 255."

`::= { appnLocalEnTgEntry 11 }`

`appnLocalEnTgSecurity OBJECT-TYPE`

`SYNTAX AppnTgSecurity`

`MAX-ACCESS read-only`

`STATUS current`

`DESCRIPTION`

`"Administratively assigned security level of this TG."`

`::= { appnLocalEnTgEntry 12 }`

`appnLocalEnTgDelay OBJECT-TYPE`

`SYNTAX AppnTgDelay`

`MAX-ACCESS read-only`

`STATUS current`

`DESCRIPTION`

`"Administratively assigned delay associated with this TG."`

`::= { appnLocalEnTgEntry 13 }`

`appnLocalEnTgUsr1 OBJECT-TYPE`

`SYNTAX INTEGER (0..255)`

`MAX-ACCESS read-only`

`STATUS current`

`DESCRIPTION`

`"First user-defined TG characteristic for this TG. This is an administratively assigned value associated with the TG."`

`::= { appnLocalEnTgEntry 14 }`

`appnLocalEnTgUsr2 OBJECT-TYPE`

`SYNTAX INTEGER (0..255)`

`MAX-ACCESS read-only`

`STATUS current`

`DESCRIPTION`

`"Second user-defined TG characteristic for this TG. This is an administratively assigned value associated with the TG."`

`::= { appnLocalEnTgEntry 15 }`

`appnLocalEnTgUsr3 OBJECT-TYPE`

`SYNTAX INTEGER (0..255)`

`MAX-ACCESS read-only`

`STATUS current`

`DESCRIPTION`

`"Third user-defined TG characteristic for this TG. This is`

```
an administratively assigned value associated with the TG."  
 ::= { appnLocalEnTgEntry 16 }  
  
-- ***** The APPN Directory Group *****  
appnDir OBJECT IDENTIFIER ::= { appnObjects 4 }  
appnDirPerf OBJECT IDENTIFIER ::= { appnDir 1 }  
  
-- The APPN Directory Group  
  
-- The APPN Directory Database  
  
-- Each APPN network node maintains directories containing information on  
-- which LUs (applications) are available and where they are located.  
-- LUs can be located in an APPN network node or in any of its attached  
-- end nodes.  
  
appnDirMaxCaches OBJECT-TYPE  
    SYNTAX Unsigned32  
    UNITS "directory entries"  
    MAX-ACCESS read-only  
    STATUS current  
    DESCRIPTION  
        "Maximum number of cache entries allowed. This is an  
        administratively assigned value."  
    ::= { appnDirPerf 1 }  
  
appnDirCurCaches OBJECT-TYPE  
    SYNTAX Gauge32  
    UNITS "directory entries"  
    MAX-ACCESS read-only  
    STATUS current  
    DESCRIPTION  
        "Current number of cache entries."  
    ::= { appnDirPerf 2 }  
  
appnDirCurHomeEntries OBJECT-TYPE  
    SYNTAX Gauge32  
    UNITS "directory entries"  
    MAX-ACCESS read-only  
    STATUS current  
    DESCRIPTION  
        "Current number of home entries."  
    ::= { appnDirPerf 3 }
```

```
appnDirRegEntries OBJECT-TYPE
    SYNTAX Gauge32
    UNITS "directory entries"
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "Current number of registered entries."
    ::= { appnDirPerf 4 }

appnDirInLocates OBJECT-TYPE
    SYNTAX AppnNodeCounter
    UNITS "Locate messages"
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "Number of directed Locates received since the node was last
         re-initialized."
    ::= { appnDirPerf 5 }

appnDirInBcastLocates OBJECT-TYPE
    SYNTAX AppnNodeCounter
    UNITS "Locate messages"
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "Number of broadcast Locates received since the node was last
         re-initialized."
    ::= { appnDirPerf 6 }

appnDirOutLocates OBJECT-TYPE
    SYNTAX AppnNodeCounter
    UNITS "Locate messages"
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "Number of directed Locates sent since the node was last
         re-initialized."
    ::= { appnDirPerf 7 }

appnDirOutBcastLocates OBJECT-TYPE
    SYNTAX AppnNodeCounter
    UNITS "Locate messages"
    MAX-ACCESS read-only
    STATUS current
```

```
DESCRIPTION
"Number of broadcast Locates sent since the node was last
re-initialized."
 ::= { appnDirPerf 8 }

appnDirNotFoundLocates OBJECT-TYPE
 SYNTAX AppnNodeCounter
 UNITS "Locate messages"
 MAX-ACCESS read-only
 STATUS current
 DESCRIPTION
"Number of directed Locates returned with a 'not found' since
the node was last re-initialized."
 ::= { appnDirPerf 9 }

appnDirNotFoundBcastLocates OBJECT-TYPE
 SYNTAX AppnNodeCounter
 UNITS "Locate messages"
 MAX-ACCESS read-only
 STATUS current
 DESCRIPTION
"Number of broadcast Locates returned with a 'not found' since
the node was last re-initialized."
 ::= { appnDirPerf 10 }

appnDirLocateOutstands OBJECT-TYPE
 SYNTAX Gauge32
 UNITS "Locate messages"
 MAX-ACCESS read-only
 STATUS current
 DESCRIPTION
"Current number of outstanding Locates, both directed and
broadcast. This value varies. A value of zero indicates
that no Locates are unanswered."
 ::= { appnDirPerf 11 }

--APPN Directory table
-- This table contains information about all known LUs.

appnDirTable OBJECT-TYPE
 SYNTAX SEQUENCE OF AppnDirEntry
 MAX-ACCESS not-accessible
 STATUS current
```

```
DESCRIPTION
  "Table containing information about all known LUs."
 ::= { appnDir 2 }

appnDirEntry OBJECT-TYPE
  SYNTAX AppnDirEntry
  MAX-ACCESS not-accessible
  STATUS current
  DESCRIPTION
    "This table is indexed by the LU name."

INDEX
  {appnDirLuName}

 ::= { appnDirTable 1 }

AppnDirEntry ::= SEQUENCE {
  appnDirLuName                  DisplayString,
  appnDirNnServerName            SnaControlPointName,
  appnDirLuOwnerName             SnaControlPointName,
  appnDirLuLocation               INTEGER,
  appnDirType                     INTEGER
}

appnDirLuName OBJECT-TYPE
  SYNTAX DisplayString (SIZE (1..17))
  MAX-ACCESS not-accessible
  STATUS current
  DESCRIPTION
    "Fully qualified network LU name in the domain of the
     serving network node. Entries take one of three forms:
      - Explicit entries do not contain the character '*'.
      - Partial wildcard entries have the form 'ccc*', where
        'ccc' represents one to sixteen characters in a
        legal SNA LuName.
      - A full wildcard entry consists of the single
        character '*'"
 ::= { appnDirEntry 1 }

appnDirNnServerName OBJECT-TYPE
  SYNTAX SnaControlPointName
  MAX-ACCESS read-only
  STATUS current
  DESCRIPTION
    "Fully qualified control point (CP) name of the network node"
```

server. For unassociated end node entries, a zero-length string is returned."

::= { appnDirEntry 2 }

appnDirLuOwnerName OBJECT-TYPE
SYNTAX SnaControlPointName
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"Fully qualified CP name of the node at which the LU is located. This name is the same as the serving NN name when the LU is located at a network node. It is also the same as the fully qualified LU name when this is the control point LU for this node."

::= { appnDirEntry 3 }

appnDirLuLocation OBJECT-TYPE
SYNTAX INTEGER {
 local(1), --Local
 domain(2), --Domain
 xdomain(3) --Cross Domain
}
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"Specifies the location of the LU with respect to the local node."

::= { appnDirEntry 4 }

appnDirType OBJECT-TYPE
SYNTAX INTEGER {
 home(1), --defined as home entry
 cache(2), --learned over time
 registered(3) --registered by end node
}
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"Directory types are:
1 - Home
The LU is in the domain of the local node, and the LU information has been configured at the local node.

2 - Cache
The LU has previously been located by a broadcast

search, and the location information has been saved.

3 - Registered
The LU is at an end node that is in the domain of the local network node. Registered entries are registered by the served end node."

`::= { appnDirEntry 5 }`

-- ***** The APPN Class of Service Group *****

`appnCos OBJECT IDENTIFIER ::= { appnObjects 5 }`

-- The APPN Class of Service (COS)

-- Class of Service is a means of expressing the quality of routes and
-- the transmission priority of traffic that flows on these routes.
-- The quality of routes is specified by two tables, a COS weight table
-- for TGS and a COS weight table for nodes. Values in these COS tables
-- are administratively assigned at each APPN node, with seven default
-- tables specified by the APPN architecture.

-- *****

`appnCosModeTable OBJECT-TYPE`
SYNTAX SEQUENCE OF AppnCosModeEntry
MAX-ACCESS not-accessible
STATUS current
DESCRIPTION
"Table representing all of the defined mode names for this
node. The table contains the matching COS name for each
mode name."

`::= { appnCos 1 }`

`appnCosModeEntry OBJECT-TYPE`
SYNTAX AppnCosModeEntry
MAX-ACCESS not-accessible
STATUS current
DESCRIPTION
"This table is indexed by the mode name."

INDEX
`{appnCosModeName}`

`::= { appnCosModeTable 1 }`

`AppnCosModeEntry ::= SEQUENCE {`

```
appnCosModeName      SnaModeName,
appnCosModeCosName   SnaClassOfServiceName
}

appnCosModeName OBJECT-TYPE
SYNTAX SnaModeName
MAX-ACCESS not-accessible
STATUS current
DESCRIPTION
    "Administratively assigned name for this mode."
::= { appnCosModeEntry 1 }

appnCosModeCosName OBJECT-TYPE
SYNTAX SnaClassOfServiceName
MAX-ACCESS read-only
STATUS current
DESCRIPTION
    "Administratively assigned name for this class of service."
::= { appnCosModeEntry 2 }

-- *****
appnCosNameTable OBJECT-TYPE
SYNTAX SEQUENCE OF AppnCosNameEntry
MAX-ACCESS not-accessible
STATUS current
DESCRIPTION
    "Table mapping all of the defined class-of-service names for
this node to their network transmission priorities."
::= { appnCos 2 }

appnCosNameEntry OBJECT-TYPE
SYNTAX AppnCosNameEntry
MAX-ACCESS not-accessible
STATUS current
DESCRIPTION
    "The COS name is the index to this table.

INDEX
    {appnCosName}

::= { appnCosNameTable 1 }

AppnCosNameEntry ::= SEQUENCE {
    appnCosName          SnaClassOfServiceName,
```

```

appnCosTransPriority    INTEGER
}

appnCosName OBJECT-TYPE
SYNTAX SnaClassName
MAX-ACCESS not-accessible
STATUS current
DESCRIPTION
  "Administratively assigned name for this class of service."
::= { appnCosNameEntry 1 }

appnCosTransPriority OBJECT-TYPE
SYNTAX INTEGER {
    low(1),          --X'01'
    medium(2),       --X'02'
    high(3),         --X'03'
    network(4)       --X'04'
}
MAX-ACCESS read-only
STATUS current
DESCRIPTION
  "Transmission priority for this class of service:
    low(1)      - (X'01'):  low priority
    medium(2)    - (X'02'):  medium priority
    high(3)      - (X'03'):  high priority
    network(4)   - (X'04'):  network priority"
::= { appnCosNameEntry 2 }

-- *****
appnCosNodeRowTable OBJECT-TYPE
SYNTAX SEQUENCE OF AppnCosNodeRowEntry
MAX-ACCESS not-accessible
STATUS current
DESCRIPTION
  "This table contains all node-row information for all classes
  of service defined in this node."
::= { appnCos 3 }

appnCosNodeRowEntry OBJECT-TYPE
SYNTAX AppnCosNodeRowEntry
MAX-ACCESS not-accessible
STATUS current
DESCRIPTION

```

```

    "A node entry for a given class of service."
```

INDEX
{appnCosNodeRowName,
 appnCosNodeRowIndex}

::= { appnCosNodeRowTable 1 }

AppnCosNodeRowEntry ::= SEQUENCE {
 appnCosNodeRowName SnaClassName,
 appnCosNodeRowIndex INTEGER,
 appnCosNodeRowWgt DisplayString,
 appnCosNodeRowResistMin INTEGER,
 appnCosNodeRowResistMax INTEGER,
 appnCosNodeRowMinCongestAllow INTEGER,
 appnCosNodeRowMaxCongestAllow INTEGER
}

appnCosNodeRowName OBJECT-TYPE
SYNTAX SnaClassName
MAX-ACCESS not-accessible
STATUS current
DESCRIPTION
"Administratively assigned name for this class of service."
::= { appnCosNodeRowEntry 1 }

appnCosNodeRowIndex OBJECT-TYPE
SYNTAX INTEGER (0..255)
MAX-ACCESS not-accessible
STATUS current
DESCRIPTION
"Subindex under appnCosNodeRowName, corresponding to a row in
the node table for the class of service identified in
appnCosNodeRowName.
For each class of service, this subindex orders rows in the
appnCosNodeRowTable in the same order as that used for route
calculation in the APPN node."
::= { appnCosNodeRowEntry 2 }

appnCosNodeRowWgt OBJECT-TYPE
SYNTAX DisplayString (SIZE (1..64))
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"Weight to be associated with the nodes that fit the criteria

specified by this node row.

This value can either be a character representation of an integer, or a formula for calculating the weight."

::= { appnCosNodeRowEntry 3 }

appnCosNodeRowResistMin OBJECT-TYPE
SYNTAX INTEGER (0..255)
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"Minimum route addition resistance value for this node.
Range of values is 0-255. The lower the value, the more desirable the node is for intermediate routing."

::= { appnCosNodeRowEntry 4 }

appnCosNodeRowResistMax OBJECT-TYPE
SYNTAX INTEGER (0..255)
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"Maximum route addition resistance value for this node.
Range of values is 0-255. The lower the value, the more desirable the node is for intermediate routing."

::= { appnCosNodeRowEntry 5 }

appnCosNodeRowMinCongestAllow OBJECT-TYPE
SYNTAX INTEGER (0..1)
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"Indicates whether low congestion will be tolerated. This object and appnCosNodeRowMaxCongestAllow together delineate a range of acceptable congestion states for a node. For the ordered pair (minimum congestion allowed, maximum congestion allowed), the values are interpreted as follows:

- (0,0): only low congestion is acceptable
- (0,1): either low or high congestion is acceptable
- (1,1): only high congestion is acceptable.

Note that the combination (1,0) is not defined, since it would identify a range whose lower bound was high congestion and whose upper bound was low congestion."

```

 ::= { appnCosNodeRowEntry 6 }

appnCosNodeRowMaxCongestAllow OBJECT-TYPE
    SYNTAX INTEGER (0..1)
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "Indicates whether low congestion will be tolerated. This
        object and appnCosNodeRowMinCongestAllow together delineate a
        range of acceptable congestion states for a node. For the
        ordered pair (minimum congestion allowed, maximum congestion
        allowed), the values are interpreted as follows:
        - (0,0): only low congestion is acceptable
        - (0,1): either low or high congestion is acceptable
        - (1,1): only high congestion is acceptable.

Note that the combination (1,0) is not defined, since it
would identify a range whose lower bound was high congestion
and whose upper bound was low congestion."

```

```

 ::= { appnCosNodeRowEntry 7 }

-- *****
appnCosTgRowTable OBJECT-TYPE
    SYNTAX SEQUENCE OF AppnCosTgRowEntry
    MAX-ACCESS not-accessible
    STATUS current
    DESCRIPTION
        "Table containing all the TG-row information for all classes of
        service defined in this node."

```

```

 ::= { appnCos 4 }

appnCosTgRowEntry OBJECT-TYPE
    SYNTAX AppnCosTgRowEntry
    MAX-ACCESS not-accessible
    STATUS current
    DESCRIPTION
        "A TG entry for a given class of service.

INDEX
    {appnCosTgRowName,
     appnCosTgRowIndex}

 ::= { appnCosTgRowTable 1 }

```

```

AppnCosTgRowEntry ::= SEQUENCE {
    appnCosTgRowName           SnaClassOfServiceName,
    appnCosTgRowIndex          INTEGER,
    appnCosTgRowWgt            DisplayString,
    appnCosTgRowEffCapMin      AppnTgEffectiveCapacity,
    appnCosTgRowEffCapMax      AppnTgEffectiveCapacity,
    appnCosTgRowConnCostMin    INTEGER,
    appnCosTgRowConnCostMax    INTEGER,
    appnCosTgRowByteCostMin    INTEGER,
    appnCosTgRowByteCostMax    INTEGER,
    appnCosTgRowSecurityMin    AppnTgSecurity,
    appnCosTgRowSecurityMax    AppnTgSecurity,
    appnCosTgRowDelayMin       AppnTgDelay,
    appnCosTgRowDelayMax       AppnTgDelay,
    appnCosTgRowUsr1Min        INTEGER,
    appnCosTgRowUsr1Max        INTEGER,
    appnCosTgRowUsr2Min        INTEGER,
    appnCosTgRowUsr2Max        INTEGER,
    appnCosTgRowUsr3Min        INTEGER,
    appnCosTgRowUsr3Max        INTEGER
}

```

```

appnCosTgRowName OBJECT-TYPE
    SYNTAX SnaClassOfServiceName
    MAX-ACCESS not-accessible
    STATUS current
    DESCRIPTION
        "Administratively assigned name for this class of service."
    ::= { appnCosTgRowEntry 1 }

```

```

appnCosTgRowIndex OBJECT-TYPE
    SYNTAX INTEGER (0..255)
    MAX-ACCESS not-accessible
    STATUS current
    DESCRIPTION
        "Subindex under appnCosTgRowName, corresponding to a row in the
         TG table for the class of service identified in
         appnCosTgRowName.

        For each class of service, this subindex orders rows in the
        appnCosTgRowTable in the same order as that used for route
        calculation in the APPN node."
    ::= { appnCosTgRowEntry 2 }

```

```

appnCosTgRowWgt OBJECT-TYPE
    SYNTAX DisplayString (SIZE (1..64))

```

```
MAX-ACCESS read-only
STATUS current
DESCRIPTION
  "Weight to be associated with the TGs that fit the criteria
   specified by this TG row.

This value can either be a character representation of an
integer, or a formula for calculating the weight."

 ::= { appnCosTgRowEntry 3 }

appnCosTgRowEffCapMin OBJECT-TYPE
  SYNTAX AppnTgEffectiveCapacity
  MAX-ACCESS read-only
  STATUS current
  DESCRIPTION
    "Minimum acceptable capacity for this class of service."

 ::= { appnCosTgRowEntry 4 }

appnCosTgRowEffCapMax OBJECT-TYPE
  SYNTAX AppnTgEffectiveCapacity
  MAX-ACCESS read-only
  STATUS current
  DESCRIPTION
    "Maximum acceptable capacity for this class of service."

 ::= { appnCosTgRowEntry 5 }

appnCosTgRowConnCostMin OBJECT-TYPE
  SYNTAX INTEGER (0..255)
  MAX-ACCESS read-only
  STATUS current
  DESCRIPTION
    "Minimum acceptable cost per connect time for this class of
     service.

Cost per connect time: a value representing the relative
cost per unit of time to use this TG. Range is from 0, which
means no cost, to 255."

 ::= { appnCosTgRowEntry 6 }

appnCosTgRowConnCostMax OBJECT-TYPE
  SYNTAX INTEGER (0..255)
  MAX-ACCESS read-only
  STATUS current
  DESCRIPTION
```

"Maximum acceptable cost per connect time for this class of service.

Cost per connect time: a value representing the relative cost per unit of time to use this TG. Range is from 0, which means no cost, to 255."

`::= { appnCosTgRowEntry 7 }`

`appnCosTgRowByteCostMin` OBJECT-TYPE

SYNTAX INTEGER (0..255)

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Minimum acceptable cost per byte transmitted for this class of service.

Cost per byte transmitted: a value representing the relative cost per unit of time to use this TG. Range is from 0, which means no cost, to 255."

`::= { appnCosTgRowEntry 8 }`

`appnCosTgRowByteCostMax` OBJECT-TYPE

SYNTAX INTEGER (0..255)

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Maximum acceptable cost per byte transmitted for this class of service.

Cost per byte transmitted: a value representing the relative cost of transmitting a byte over this TG. Range is from 0, which means no cost, to 255."

`::= { appnCosTgRowEntry 9 }`

`appnCosTgRowSecurityMin` OBJECT-TYPE

SYNTAX AppnTgSecurity

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Minimum acceptable security for this class of service."

`::= { appnCosTgRowEntry 10 }`

`appnCosTgRowSecurityMax` OBJECT-TYPE

SYNTAX AppnTgSecurity

```
MAX-ACCESS read-only
STATUS current
DESCRIPTION
    "Maximum acceptable security for this class of service."
::= { appnCosTgRowEntry 11 }

appnCosTgRowDelayMin OBJECT-TYPE
    SYNTAX AppnTgDelay
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "Minimum acceptable propagation delay for this class of
         service."
::= { appnCosTgRowEntry 12 }

appnCosTgRowDelayMax OBJECT-TYPE
    SYNTAX AppnTgDelay
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "Maximum acceptable propagation delay for this class of
         service."
::= { appnCosTgRowEntry 13 }

appnCosTgRowUsr1Min OBJECT-TYPE
    SYNTAX INTEGER (0..255)
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "Minimum acceptable value for this user-defined
         characteristic."
::= { appnCosTgRowEntry 14 }

appnCosTgRowUsr1Max OBJECT-TYPE
    SYNTAX INTEGER (0..255)
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "Maximum acceptable value for this user-defined
         characteristic."
::= { appnCosTgRowEntry 15 }

appnCosTgRowUsr2Min OBJECT-TYPE
```

```
SYNTAX INTEGER (0..255)
MAX-ACCESS read-only
STATUS current
DESCRIPTION
  "Minimum acceptable value for this user-defined
   characteristic."
 ::= { appnCosTgRowEntry 16 }

appnCosTgRowUsr2Max OBJECT-TYPE
  SYNTAX INTEGER (0..255)
  MAX-ACCESS read-only
  STATUS current
  DESCRIPTION
    "Maximum acceptable value for this user-defined
     characteristic."
 ::= { appnCosTgRowEntry 17 }

appnCosTgRowUsr3Min OBJECT-TYPE
  SYNTAX INTEGER (0..255)
  MAX-ACCESS read-only
  STATUS current
  DESCRIPTION
    "Minimum acceptable value for this user-defined
     characteristic."
 ::= { appnCosTgRowEntry 18 }

appnCosTgRowUsr3Max OBJECT-TYPE
  SYNTAX INTEGER (0..255)
  MAX-ACCESS read-only
  STATUS current
  DESCRIPTION
    "Maximum acceptable value for this user-defined
     characteristic."
 ::= { appnCosTgRowEntry 19 }

-- *****
-- Intermediate Session Information
-- *****
appnSessIntermediate OBJECT IDENTIFIER ::= { appnObjects 6 }

-- *****
-- Intermediate Session Information Global Objects
-- *****
-- The following simple objects allow the collection of intermediate
```

```
-- session Information to be started and stopped.
-- ****
appnIsInGlobal OBJECT IDENTIFIER ::= { appnSessIntermediate 1 }
```

appnIsInGlobeCtrAdminStatus OBJECT-TYPE

```
SYNTAX INTEGER {
    notActive(1),
    active(2),
    ready(3)
}
```

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"Object by which a Management Station can deactivate or activate capture of intermediate-session counts and names, by setting the value to notActive(1) or active(2), respectively. The value ready(3) is returned on GET operations until a SET has been processed; after that the value received on the most recent SET is returned.

The counts referred to here are the eight objects in the AppnIsInTable, from appnIsInP2SFmdPiis through appnIsInS2PNonFmdBytes. The names are the four objects in this table, from appnIsInPriLuName through appnIsInCosName.

Setting this object to the following values has the following effects:

notActive(1)	stop collecting count data. If a count is queried, it returns the value 0. Collection of names may, but need not be, disabled.
active(2)	start collecting count data. If it is supported, collection of names is enabled."

```
::= { appnIsInGlobal 1 }
```

appnIsInGlobeCtrOperStatus OBJECT-TYPE

```
SYNTAX INTEGER {
    notActive(1),
    active(2)
}
```

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Indicates whether or not the intermediate session counts are active. The counts referred to here are the eight objects in the AppnIsInTable, from appnIsInP2SFmdPiis through

`appnIsInS2PNonFmdBytes`. These eight counts are of type Unsigned32 rather than Counter32 because when this object enters the notActive state, either because a Management Station has set `appnInInGlobeCtrAdminStatus` to notActive or because of a locally-initiated transition, the counts are all reset to 0.

The values for this object are:

```
notActive(1): collection of counts is not active; if it
               is queried, a count returns the value 0.
active(2):      collection of counts is active."
```

```
::= { appnIsInGlobal 2 }
```

`appnIsInGlobeCtrStatusTime` OBJECT-TYPE

SYNTAX TimeTicks

UNITS "hundredths of a second"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The time since the `appnIsInGlobeCtrOperStatus` object last changed, measured in hundredths of a second. This time can be used to identify when this change occurred in relation to other events in the agent, such as the last time the APPN node was re-initialized."

```
::= { appnIsInGlobal 3 }
```

`appnIsInGlobeRscv` OBJECT-TYPE

SYNTAX INTEGER {

```
    notActive(1),
    active(2)
}
```

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"Indicates the current route selection control vector (RSCV) collection option in effect, and allows a Management Station to change the option."

The values for this object are:

```
notActive(1): collection of route selection control vectors
               is not active.
active(2):      collection of route selection control vectors
               is active."
```

```
 ::= { appnIsInGlobal 4 }

appnIsInGlobeRscvTime OBJECT-TYPE
    SYNTAX TimeTicks
    UNITS "hundredths of a second"
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "The time since the appnIsInGlobeRscv object last changed,
         measured in hundredths of a second. This time can be used to
         identify when this change occurred in relation to other events
         in the agent, such as the last time the APPN node was
         re-initialized."

 ::= { appnIsInGlobal 5 }

appnIsInGlobeActSess OBJECT-TYPE
    SYNTAX Gauge32
    UNITS "sessions"
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "The number of currently active intermediate sessions."

 ::= { appnIsInGlobal 6 }

appnIsInGlobeHprBfActSess OBJECT-TYPE
    SYNTAX Gauge32
    UNITS "sessions"
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "The number of currently active HPR intermediate sessions.

 ::= { appnIsInGlobal 7 }

-- ****
-- Intermediate Session Information Table
-- ****
-- This table contains information on intermediate sessions
-- which are currently active.
-- ****
appnIsInTable OBJECT-TYPE
    SYNTAX SEQUENCE OF AppnIsInEntry
    MAX-ACCESS not-accessible
    STATUS current
    DESCRIPTION
```

```

"Intermediate Session Information Table"

 ::= { appnSessIntermediate 2 }

appnIsInEntry OBJECT-TYPE
  SYNTAX AppnIsInEntry
  MAX-ACCESS not-accessible
  STATUS current
  DESCRIPTION
    "Entry of Intermediate Session Information Table."

INDEX
  { appnIsInFqCpName,
    appnIsInPcid }

 ::= { appnIsInTable 1 }

AppnIsInEntry ::= SEQUENCE {
  appnIsInFqCpName          SnaControlPointName,
  appnIsInPcid               OCTET STRING,
  appnIsInSessState          INTEGER,
  appnIsInPriLuName          DisplayString,
  appnIsInSecLuName          DisplayString,
  appnIsInModeName           SnaModeName,
  appnIsInCosName            SnaClassOfServiceName,
  appnIsInTransPriority      INTEGER,
  appnIsInSessType            INTEGER,
  appnIsInSessUpTime          TimeTicks,
  appnIsInCtrUpTime          TimeTicks,
  appnIsInP2SFmdPius          Unsigned32,
  appnIsInS2PFmdPius          Unsigned32,
  appnIsInP2SNonFmdPius       Unsigned32,
  appnIsInS2PNonFmdPius       Unsigned32,
  appnIsInP2SFmdBytes         Unsigned32,
  appnIsInS2PFmdBytes         Unsigned32,
  appnIsInP2SNonFmdBytes      Unsigned32,
  appnIsInS2PNonFmdBytes      Unsigned32,
  appnIsInPsAdjCpName         SnaControlPointName,
  appnIsInPsAdjTgNum          INTEGER,
  appnIsInPsSendMaxBtuSize    INTEGER,
  appnIsInPsSendPacingType    INTEGER,
  appnIsInPsSendRpc            Gauge32,
  appnIsInPsSendNxWndwSize     Gauge32,
  appnIsInPsRecvPacingType    INTEGER,
}

```

```

appnIsInPsRecvRpc          Gauge32,
appnIsInPsRecvNxWndwSize   Gauge32,

appnIsInSsAdjCpName        SnaControlPointName,
appnIsInSsAdjTgNum         INTEGER,
appnIsInSsSendMaxBtuSize  INTEGER,
appnIsInSsSendPacingType  INTEGER,
appnIsInSsSendRpc          Gauge32,
appnIsInSsSendNxWndwSize  Gauge32,
appnIsInSsRecvPacingType  INTEGER,
appnIsInSsRecvRpc          Gauge32,
appnIsInSsRecvNxWndwSize  Gauge32,

appnIsInRouteInfo          OCTET STRING,

appnIsInRtpNceId           OCTET STRING,
appnIsInRtpTcid             OCTET STRING
}

appnIsInFqCpName OBJECT-TYPE
SYNTAX SnaControlPointName
MAX-ACCESS not-accessible
STATUS current
DESCRIPTION
"The network-qualified control point name of the node at which
the session and PCID originated. For APPN and LEN nodes, this
is either CP name of the APPN node at which the origin LU is
located or the CP name of the NN serving the LEN node at which
the origin LU is located. For resources served by a dependent
LU requester (DLUR), it is the name of the owning system
services control point (SSCP)."

 ::= { appnIsInEntry 1 }

appnIsInPcid OBJECT-TYPE
SYNTAX OCTET STRING (SIZE (8))
MAX-ACCESS not-accessible
STATUS current
DESCRIPTION
"The procedure correlation identifier (PCID) of a session. It
is an 8-byte value assigned by the primary LU."

 ::= { appnIsInEntry 2 }

appnIsInSessState OBJECT-TYPE
SYNTAX INTEGER {
    inactive(1),
    pendactive(2),
}

```

```
        active(3),
        pendinact(4)
    }
MAX-ACCESS read-write
STATUS current
DESCRIPTION
    "Indicates the state of the session:

        inactive(1) - session is inactive
        pendactive(2) - session is pending active
        active(3) - session is active
        pendinact(4) - session is pending inactive

    Active sessions can be deactivated by setting this object
    to inactive(1)."

 ::= { appnIsInEntry 3 }

appnIsInPriLuName OBJECT-TYPE
    SYNTAX DisplayString (SIZE (0..17))
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "The primary LU name of the session. A zero-length
        string indicates that this name is not available."

 ::= { appnIsInEntry 4 }

appnIsInSecLuName OBJECT-TYPE
    SYNTAX DisplayString (SIZE (0..17))
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "The secondary LU name of the session. A zero-length
        string indicates that this name is not available."

 ::= { appnIsInEntry 5 }

appnIsInModeName OBJECT-TYPE
    SYNTAX SnaModeName
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "The mode name used for this session."

 ::= { appnIsInEntry 6 }

appnIsInCosName OBJECT-TYPE
```

```

SYNTAX SnaClassOfServiceName
MAX-ACCESS read-only
STATUS current
DESCRIPTION
  "The Class of Service (COS) name used for this session."
 ::= { appnIsInEntry 7 }

appnIsInTransPriority OBJECT-TYPE
  SYNTAX INTEGER {
    low(1),          --X'01'
    medium(2),       --X'02'
    high(3),         --X'03'
    network(4)       --X'04'
  }
  MAX-ACCESS read-only
  STATUS current
  DESCRIPTION
    "Transmission priority for this class of service. Values are:
     low(1) - (X'01'): low priority
     medium(2) - (X'02'): medium priority
     high(3) - (X'03'): high priority
     network(4) - (X'04'): network priority"
 ::= { appnIsInEntry 8 }

appnIsInSessType OBJECT-TYPE
  SYNTAX INTEGER {
    unknown(1),
    lu62(2),
    lu0thru3(3),
    lu62dlur(4),
    lu0thru3dlur(5)
  }
  MAX-ACCESS read-only
  STATUS current
  DESCRIPTION
    "The type of intermediate session. Defined values are
     unknown      The session type is not known.
     lu62         A session between LUs of type 6.2
                  (as indicated by the LU type in Bind)
     lu0thru3    A session between LUs of type 0, 1, 2, or 3
                  (as indicated by the LU type in Bind)

```

lu62dlur A session between LUs of type 6.2
(as indicated by the LU type in Bind).
One of the LUs is a dependent LU supported
by the dependent LU requester (DLUR)
function at this node.

lu0thru3dlur A session between LUs of type 0, 1, 2, or 3
(as indicated by the LU type in Bind)
One of the LUs is a dependent LU supported
by the dependent LU requester (DLUR)
function at this node."

::= { appnIsInEntry 9 }

appnIsInSessUpTime OBJECT-TYPE
SYNTAX TimeTicks
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"Length of time the session has been active, measured in
hundredths of a second."

::= { appnIsInEntry 10 }

appnIsInCtrUpTime OBJECT-TYPE
SYNTAX TimeTicks
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"Length of time the session counters have been active, measured
in hundredths of a second."

::= { appnIsInEntry 11 }

appnIsInP2SFmdPius OBJECT-TYPE
SYNTAX Unsigned32
UNITS "path information units (PIUs)"
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"Number of function management data (FMD) path information
units (PIUs) sent from the Primary LU to the Secondary LU since
the counts were last activated."

::= { appnIsInEntry 12 }

appnIsInS2PFmdPius OBJECT-TYPE
SYNTAX Unsigned32

```
UNITS "path information units (PIUs)"
MAX-ACCESS read-only
STATUS current
DESCRIPTION
  "Number of FMD PIUs sent from the Secondary LU to the Primary
   LU since the counts were last activated."
 ::= { appnIsInEntry 13 }

appnIsInP2SNonFmdPiUs OBJECT-TYPE
  SYNTAX Unsigned32
  UNITS "path information units (PIUs)"
  MAX-ACCESS read-only
  STATUS current
  DESCRIPTION
    "Number of non-FMD PIUs sent from the Primary LU to the
     Secondary LU since the counts were last activated."
 ::= { appnIsInEntry 14 }

appnIsInS2PNonFmdPiUs OBJECT-TYPE
  SYNTAX Unsigned32
  UNITS "path information units (PIUs)"
  MAX-ACCESS read-only
  STATUS current
  DESCRIPTION
    "Number of non-FMD PIUs sent from the Secondary LU to the
     Primary LU since the counts were last activated."
 ::= { appnIsInEntry 15 }

appnIsInP2SFmdBytes OBJECT-TYPE
  SYNTAX Unsigned32
  UNITS "bytes"
  MAX-ACCESS read-only
  STATUS current
  DESCRIPTION
    "Number of FMD bytes sent from the Primary LU to the Secondary
     LU since the counts were last activated."
 ::= { appnIsInEntry 16 }

appnIsInS2PFmdBytes OBJECT-TYPE
  SYNTAX Unsigned32
  UNITS "bytes"
  MAX-ACCESS read-only
  STATUS current
  DESCRIPTION
```

"Number of FMD bytes sent from the Secondary LU to the Primary LU since the counts were last activated."

::= { appnIsInEntry 17 }

appnIsInP2SNonFmdBytes OBJECT-TYPE

SYNTAX Unsigned32

UNITS "bytes"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Number of non-FMD bytes sent from the Primary LU to the Secondary LU since the counts were last activated."

::= { appnIsInEntry 18 }

appnIsInS2PNonFmdBytes OBJECT-TYPE

SYNTAX Unsigned32

UNITS "bytes"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Number of non-FMD bytes sent from the Secondary LU to the Primary LU since the counts were last activated."

::= { appnIsInEntry 19 }

appnIsInPsAdjCpName OBJECT-TYPE

SYNTAX SnaControlPointName

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The primary stage adjacent CP name of this session. If the session stage traverses an RTP connection, the CP name of the remote RTP endpoint is returned."

::= { appnIsInEntry 20 }

appnIsInPsAdjTgNum OBJECT-TYPE

SYNTAX INTEGER (0..300)

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The primary stage adjacent transmission group (TG) number associated with this session. If the session stage traverses an RTP connection, the value 256 is returned.

Values between 257 and 300 are available for other possible

TG 'stand-ins' that may be added to APPN in the future."

`::= { appnIsInEntry 21 }`

appnIsInPsSendMaxBtuSize OBJECT-TYPE
SYNTAX INTEGER (99..32767)
UNITS "bytes"
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"The primary stage maximum basic transmission unit (BTU) size
for sending data."

`::= { appnIsInEntry 22 }`

appnIsInPsSendPacingType OBJECT-TYPE
SYNTAX INTEGER {
 fixed(1),
 adaptive(2)
}
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"The primary stage type of pacing being used for sending data."

`::= { appnIsInEntry 23 }`

appnIsInPsSendRpc OBJECT-TYPE
SYNTAX Gauge32
UNITS "message units (MUs)"
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"The primary stage send residual pace count. This represents
the primary stage number of message units (MUs) that can still
be sent in the current session window."

`::= { appnIsInEntry 24 }`

appnIsInPsSendNxWndwSize OBJECT-TYPE
SYNTAX Gauge32
UNITS "message units (MUs)"
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"The primary stage size of the next window which will be used
to send data."

```
::= { appnIsInEntry 25 }

appnIsInPsRecvPacingType OBJECT-TYPE
    SYNTAX INTEGER {
        fixed(1),
        adaptive(2)
    }
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "The primary stage type of pacing being used for receiving
        data."

::= { appnIsInEntry 26 }

appnIsInPsRecvRpc OBJECT-TYPE
    SYNTAX Gauge32
    UNITS "message units (MUs)"
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "The primary stage receive residual pace count. This
        represents the primary stage number of message units (MUs) that
        can still be received in the current session window."

::= { appnIsInEntry 27 }

appnIsInPsRecvNxWndwSize OBJECT-TYPE
    SYNTAX Gauge32
    UNITS "message units (MUs)"
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "The primary stage size of the next window which will be used
        to receive data."

::= { appnIsInEntry 28 }

appnIsInSsAdjCpName OBJECT-TYPE
    SYNTAX SnaControlPointName
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "The secondary stage adjacent CP name of this session. If the
        session stage traverses an RTP connection, the CP name of the
        remote RTP endpoint is returned."

::= { appnIsInEntry 29 }
```

```
appnIsInSsAdjTgNum OBJECT-TYPE
    SYNTAX INTEGER (0..300)
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "The secondary stage adjacent transmission group (TG) number
         associated with this session. If the session stage traverses
         an RTP connection, the value 256 is returned."
```

Values between 257 and 300 are available for other possible
TG 'stand-ins' that may be added to APPN in the future."

```
::= { appnIsInEntry 30 }
```

```
appnIsInSsSendMaxBtuSize OBJECT-TYPE
    SYNTAX INTEGER (99..32767)
    UNITS "bytes"
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "The secondary stage maximum basic transmission unit (BTU) size
         for sending data."
```

```
::= { appnIsInEntry 31 }
```

```
appnIsInSsSendPacingType OBJECT-TYPE
    SYNTAX INTEGER {
        fixed(1),
        adaptive(2)
    }
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "The secondary stage type of pacing being used for sending
         data."
```

```
::= { appnIsInEntry 32 }
```

```
appnIsInSsSendRpc OBJECT-TYPE
    SYNTAX Gauge32
    UNITS "message units (MUs)"
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "The secondary stage send residual pace count. This represents
         the secondary stage number of message units (MUs) that can
         still be sent in the current session window."
```

```
::= { appnIsInEntry 33 }

appnIsInSsSendNxWndwSize OBJECT-TYPE
    SYNTAX Gauge32
    UNITS "message units (MUs)"
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "The secondary stage size of the next window which will be used
         to send data."

::= { appnIsInEntry 34 }

appnIsInSsRecvPacingType OBJECT-TYPE
    SYNTAX INTEGER {
        fixed(1),
        adaptive(2)
    }
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "The secondary stage type of pacing being used for receiving
         data."

::= { appnIsInEntry 35 }

appnIsInSsRecvRpc OBJECT-TYPE
    SYNTAX Gauge32
    UNITS "message units (MUs)"
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "The secondary stage receive residual pace count. This
         represents the secondary stage number of message units (MUs)
         that can still be received in the current session window."

::= { appnIsInEntry 36 }

appnIsInSsRecvNxWndwSize OBJECT-TYPE
    SYNTAX Gauge32
    UNITS "message units (MUs)"
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "The secondary stage size of the next window which will be used
         to receive data.

::= { appnIsInEntry 37 }
```

```
appnIsInRouteInfo OBJECT-TYPE
    SYNTAX OCTET STRING (SIZE (0..255))
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "The route selection control vector (RSCV X'2B') used for this
        session. It is present for APPN nodes; but is not present for
        LEN nodes. The format of this vector is described in SNA
        Formats. If no RSCV is available, a zero-length string is
        returned."
    ::= { appnIsInEntry 38 }

appnIsInRtpNceId OBJECT-TYPE
    SYNTAX OCTET STRING (SIZE (1..8))
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "The HPR local Network Connection Endpoint of the session."
    ::= { appnIsInEntry 39 }

appnIsInRtpTcid OBJECT-TYPE
    SYNTAX OCTET STRING (SIZE (8))
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "The RTP connection local TCID of the session."
    ::= { appnIsInEntry 40 }

-- *****
-- Intermediate Session RTP Table
-- *****
-- This table contains information on intermediate sessions that are
-- being transported on Rapid Transport Protocol (RTP) connections by
-- High Performance Routing (HPR).
-- *****

appnIsRtpTable OBJECT-TYPE
    SYNTAX SEQUENCE OF AppnIsRtpEntry
    MAX-ACCESS not-accessible
    STATUS current
    DESCRIPTION
        "A table indicating how many ISR sessions are transported by
        each RTP connection."
    ::= { appnSessIntermediate 3 }
```

```

appnIsRtpEntry OBJECT-TYPE
    SYNTAX AppnIsRtpEntry
    MAX-ACCESS not-accessible
    STATUS current
    DESCRIPTION
        "Entry of Intermediate Session RTP Table."

INDEX
    { appnIsRtpNceId,
      appnIsRtpTcid }

::= { appnIsRtpTable 1 }

AppnIsRtpEntry ::= SEQUENCE {
    appnIsRtpNceId          OCTET STRING,
    appnIsRtpTcid            OCTET STRING,
    appnIsRtpSessions        Gauge32
}

appnIsRtpNceId OBJECT-TYPE
    SYNTAX OCTET STRING (SIZE (8))
    MAX-ACCESS not-accessible
    STATUS current
    DESCRIPTION
        "The local Network Connection Endpoint of the RTP connection."
    ::= { appnIsRtpEntry 1 }

appnIsRtpTcid OBJECT-TYPE
    SYNTAX OCTET STRING (SIZE (8))
    MAX-ACCESS not-accessible
    STATUS current
    DESCRIPTION
        "The local TCID of the RTP connection."
    ::= { appnIsRtpEntry 2 }

appnIsRtpSessions OBJECT-TYPE
    SYNTAX Gauge32
    UNITS "sessions"
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "The number of intermediate sessions using this RTP
connection."
    ::= { appnIsRtpEntry 3 }

```

```
-- ****
appnTraps          OBJECT IDENTIFIER ::= { appnMIB 2 }
-- ****

alertTrap NOTIFICATION-TYPE
OBJECTS { alertIdNumber, affectedObject }
STATUS current
DESCRIPTION
"This trap carries a 32-bit SNA Management Services (SNA/MS)
Alert ID Number, as specified in SNA/MS Formats."
::= { appnTraps 1 }

alertIdNumber OBJECT-TYPE
SYNTAX OCTET STRING (SIZE (4))
MAX-ACCESS accessible-for-notify
STATUS current
DESCRIPTION
"A 32-bit SNA Management Services (SNA/MS) Alert ID Number, as
specified in SNA/MS Formats."
::= { appnTraps 2 }

affectedObject OBJECT-TYPE
SYNTAX VariablePointer
MAX-ACCESS accessible-for-notify
STATUS current
DESCRIPTION
"The MIB object associated with the Alert condition, if there
is an object associated with it. If no associated object can
be identified, the value 0.0 is passed in the trap."
::= { appnTraps 3 }

-- ****
-- Conformance information
-- ****

appnConformance      OBJECT IDENTIFIER ::= { appnMIB 3 }
appnCompliances      OBJECT IDENTIFIER ::= { appnConformance 1 }
appnGroups            OBJECT IDENTIFIER ::= { appnConformance 2 }

-- Compliance statements
appnCompliance MODULE-COMPLIANCE
STATUS current
DESCRIPTION
"The compliance statement for the SNMPv2 entities that
```

```
implement the APPN MIB."  
  
MODULE -- this module  
  
-- Unconditionally mandatory groups  
MANDATORY-GROUPS {  
    appnGeneralConfGroup,  
    appnPortConfGroup,  
    appnLinkConfGroup,  
    appnLocalTgConfGroup,  
    appnDirTableConfGroup  
}  
  
-- Conditionally mandatory groups  
GROUP appnNnUniqueConfGroup  
DESCRIPTION  
    "The appnNnUniqueConfGroup is mandatory only for  
    network nodes."  
  
GROUP appnEnUniqueConfGroup  
DESCRIPTION  
    "The appnEnUniqueConfGroup is mandatory only for end  
    nodes."  
GROUP appnVrnConfGroup  
DESCRIPTION  
    "The appnVrnConfGroup is mandatory only for network  
    nodes and end nodes that implement virtual routing  
    node support."  
  
GROUP appnNnTopoConfGroup  
DESCRIPTION  
    "The appnNnTopoConfGroup is mandatory only for  
    network nodes."  
  
GROUP appnLocalEnTopoConfGroup  
DESCRIPTION  
    "The appnLocalEnTopoConfGroup is mandatory only for  
    network nodes."  
  
GROUP appnLocalDirPerfConfGroup  
DESCRIPTION  
    "The appnLocalDirPerfConfGroup is mandatory only for  
    APPN network nodes and end nodes."  
  
GROUP appnCosConfGroup  
DESCRIPTION  
    "The appnCosConfGroup is mandatory only for APPN  
    network nodes and end nodes."
```

```

GROUP appnIntSessConfGroup
DESCRIPTION
  "The appnIntSessConfGroup is mandatory only for
  network nodes."

GROUP appnHprBaseConfGroup
DESCRIPTION
  "The appnHprBaseConfGroup is mandatory only for nodes
  that implement the HPR base (APPN option set 1400)."

GROUP appnHprRtpConfGroup
DESCRIPTION
  "The appnHprRtpConfGroup is mandatory only for nodes
  that implement the HPR RTP tower (APPN option set
  1401)."

GROUP appnHprCtrlFlowsRtpConfGroup
DESCRIPTION
  "The appnHprCtrlFlowsRtpConfGroup is mandatory only
  for nodes that implement the HPR Control Flows over
  RTP tower (APPN option set 1402)."

GROUP appnHprBfConfGroup
DESCRIPTION
  "The appnHprBfConfGroup is mandatory only for nodes
  that implement the APPN/HPR boundary function."

GROUP appnTrapConfGroup
DESCRIPTION
  "Traps are optional for all nodes."

GROUP appnTrapNotifGroup
DESCRIPTION
  "Traps are optional for all nodes."

```

`::= {appnCompliances 1 }`

-- Units of conformance

```

appnGeneralConfGroup OBJECT-GROUP
  OBJECTS {
    appnNodeCpName,
    appnNodeMibVersion,
    appnNodeId,
    appnNodeType,
    appnNodeUpTime,
    appnNodeParallelTg,
    appnNodeAdaptiveBindPacing,
    appnNodeHprSupport,
  }

```

```
        appnNodeCounterDisconTime
    }
STATUS current
DESCRIPTION
    "A collection of objects providing the instrumentation of
APPN general information and capabilities."
::= { appnGroups 1 }

appnPortConfGroup OBJECT-GROUP
OBJECTS {
    appnPortCommand,
    appnPortOperState,
    appnPortDlcType,
    appnPortPortType,
    appnPortSIMRIM,
    appnPortLsRole,
    appnPortNegotLs,
    appnPortDynamicLinkSupport,
    appnPortMaxRcvBtuSize,
    appnPortMaxIframeWindow,
    appnPortDefLsGoodXids,
    appnPortDefLsBadXids,
    appnPortDynLsGoodXids,
    appnPortDynLsBadXids,
    appnPortSpecific,
    appnPortDlcLocalAddr,
    appnPortCounterDisconTime
}
STATUS current
DESCRIPTION
    "A collection of objects providing the instrumentation of
APPN port information."
::= { appnGroups 2 }

appnLinkConfGroup OBJECT-GROUP
OBJECTS {
    appnLsCommand,
    appnLsOperState,
    appnLsPortName,
    appnLsDlcType,
    appnLsDynamic,
    appnLsAdjCpName,
    appnLsAdjNodeType,
    appnLsTgNum,
    appnLsLimResource,
    appnLsActOnDemand,
```

```
    appnLsMigration,
    appnLsPartnerNodeId,
    appnLsCpCpSessionSupport,
    appnLsMaxSendBtuSize,
    appnLsInXidBytes,
    appnLsInMsgBytes,
    appnLsInXidFrames,
    appnLsInMsgFrames,
    appnLsOutXidBytes,
    appnLsOutMsgBytes,
    appnLsOutXidFrames,
    appnLsOutMsgFrames,
    appnLsEchoRsp,
    appnLsCurrentDelay,
    appnLsMaxDelay,
    appnLsMinDelay,
    appnLsMaxDelayTime,
    appnLsGoodXids,
    appnLsBadXids,
    appnLsSpecific,
    appnLsActiveTime,
    appnLsCurrentStateTime,
    appnLsHprSup,
    appnLsLocalAddr,
    appnLsRemoteAddr,
    appnLsRemoteLsName,
    appnLsStatusTime,
    appnLsStatusLsName,
    appnLsStatusCpName,
    appnLsStatusPartnerId,
    appnLsStatusTgNum,
    appnLsStatusGeneralSense,
    appnLsStatusRetry,
    appnLsStatusEndSense,
    appnLsStatusXidLocalSense,
    appnLsStatusXidRemoteSense,
    appnLsStatusXidByteInError,
    appnLsStatusXidBitInError,
    appnLsStatusDlcType,
    appnLsStatusLocalAddr,
    appnLsStatusRemoteAddr,
    appnLsCounterDisconTime
}
STATUS current
DESCRIPTION
  "A collection of objects providing the instrumentation of
  APPN link information."
```

```
::= { appnGroups 3 }
```

```
appnLocalTgConfGroup OBJECT-GROUP
    OBJECTS {
        appnLocalTgDestVirtual,
        appnLocalTgDlcData,
        appnLocalTgPortName,
        appnLocalTgQuiescing,
        appnLocalTgOperational,
        appnLocalTgCpCpSession,
        appnLocalTgEffCap,
        appnLocalTgConnCost,
        appnLocalTgByteCost,
        appnLocalTgSecurity,
        appnLocalTgDelay,
        appnLocalTgUsr1,
        appnLocalTgUsr2,
        appnLocalTgUsr3,
        appnLocalTgHprSup,
        appnLocalTgIntersubnet
    }
    STATUS current
    DESCRIPTION
        "A collection of objects providing the instrumentation of
         APPN local TG information."
```

```
::= { appnGroups 4 }
```

```
appnDirTableConfGroup OBJECT-GROUP
    OBJECTS {
        appnDirNnServerName,
        appnDirLuOwnerName,
        appnDirLuLocation,
        appnDirType
    }
    STATUS current
    DESCRIPTION
        "A collection of objects providing the instrumentation of the
         APPN directory database."
```

```
::= { appnGroups 5 }
```

```
appnNnUniqueConfGroup OBJECT-GROUP
    OBJECTS {
        appnNodeNnCentralDirectory,
        appnNodeNnTreeCache,
        appnNodeNnRouteAddResist,
        appnNodeNnIsr,
```

```

        appnNodeNnFrsn,
        appnNodeNnPeriBorderSup,
        appnNodeNnInterchangeSup,
        appnNodeNnExteBorderSup,
        appnNodeNnSafeStoreFreq,
        appnNodeNnRsn,
        appnNodeNnCongested,
        appnNodeNnIsrDepleted,
        appnNodeNnQuiescing,
        appnNodeNnGateway
    }
STATUS current
DESCRIPTION
    "The appnNnUniqueConfGroup is mandatory only for network
nodes."
::= { appnGroups 6 }

appnEnUniqueConfGroup OBJECT-GROUP
OBJECTS {
    appnNodeEnModeCosMap,
    appnNodeEnNnServer,
    appnNodeEnLuSearch
}
STATUS current
DESCRIPTION
    "The appnEnUniqueConfGroup is mandatory only for end nodes."
::= { appnGroups 7 }

appnVrnConfGroup OBJECT-GROUP
OBJECTS {
    appnVrnPortName
}
STATUS current
DESCRIPTION
    "The appnVrnConfGroup is mandatory only for APPN network
nodes and end nodes."
::= { appnGroups 8 }

appnNnTopoConfGroup OBJECT-GROUP
OBJECTS {
    appnNnTopoMaxNodes,
    appnNnTopoCurNumNodes,
    appnNnTopoNodePurges,
    appnNnTopoTgPurges,
    appnNnTopoTotalTduWars,
}

```

```
    appnNnNodeFREntryTimeLeft,
    appnNnNodeFRType,
    appnNnNodeFRRsn,
    appnNnNodeFRRouteAddResist,
    appnNnNodeFRCongested,
    appnNnNodeFRIsrDepleted,
    appnNnNodeFRQuiescing,
    appnNnNodeFRGateway,
    appnNnNodeFRCentralDirectory,
    appnNnNodeFRIsr,
    appnNnNodeFRGarbageCollect,
    appnNnNodeFRHprSupport,
    appnNnNodeFRPeriBorderSup,
    appnNnNodeFRInterchangeSup,
    appnNnNodeFRExteBorderSup,
    appnNnTgFREntryTimeLeft,
    appnNnTgFRDestVirtual,
    appnNnTgFRDlcData,
    appnNnTgFRRsn,
    appnNnTgFROperational,
    appnNnTgFRQuiescing,
    appnNnTgFRCpCpSession,
    appnNnTgFREffCap,
    appnNnTgFRConnCost,
    appnNnTgFRByteCost,
    appnNnTgFRSecurity,
    appnNnTgFRDelay,
    appnNnTgFRUsr1,
    appnNnTgFRUsr2,
    appnNnTgFRUsr3,
    appnNnTgFRGarbageCollect,
    appnNnTgFRSubareaNum,
    appnNnTgFRHprSup,
    appnNnTgFRDestHprTrans,
    appnNnTgFRTypeIndicator,
    appnNnTgFRIntersubnet
}
STATUS current
DESCRIPTION
  "The appnNnTopoConfGroup is mandatory only for network
  nodes."
::= { appnGroups 9 }

appnLocalEnTopoConfGroup   OBJECT-GROUP
  OBJECTS  {
    appnLocalEnTgEntryTimeLeft,
    appnLocalEnTgDestVirtual,
```

```

    appnLocalEnTgDlcData,
    appnLocalEnTgOperational,
    appnLocalEnTgCpCpSession,
    appnLocalEnTgEffCap,
    appnLocalEnTgConnCost,
    appnLocalEnTgByteCost,
    appnLocalEnTgSecurity,
    appnLocalEnTgDelay,
    appnLocalEnTgUsr1,
    appnLocalEnTgUsr2,
    appnLocalEnTgUsr3
}
STATUS current
DESCRIPTION
  "The appnLocalEnTopoConfGroup is mandatory only for network
  nodes."
::= { appnGroups 10 }

appnLocalDirPerfConfGroup OBJECT-GROUP
OBJECTS {
    appnDirMaxCaches,
    appnDirCurCaches,
    appnDirCurHomeEntries,
    appnDirRegEntries,
    appnDirInLocates,
    appnDirInBcastLocates,
    appnDirOutLocates,
    appnDirOutBcastLocates,
    appnDirNotFoundLocates,
    appnDirNotFoundBcastLocates,
    appnDirLocateOutstands
}
STATUS current
DESCRIPTION
  "The appnLocalDirPerfConfGroup is mandatory only for APPN
  network nodes and end nodes."
::= { appnGroups 11 }

appnCosConfGroup          OBJECT-GROUP
OBJECTS {
    appnCosModeCosName,
    appnCosTransPriority,
    appnCosNodeRowWgt,
    appnCosNodeRowResistMin,
    appnCosNodeRowResistMax,
    appnCosNodeRowMinCongestAllow,

```

```
    appnCosNodeRowMaxCongestAllow,
    appnCosTgRowWgt,
    appnCosTgRowEffCapMin,
    appnCosTgRowEffCapMax,
    appnCosTgRowConnCostMin,
    appnCosTgRowConnCostMax,
    appnCosTgRowByteCostMin,
    appnCosTgRowByteCostMax,
    appnCosTgRowSecurityMin,
    appnCosTgRowSecurityMax,
    appnCosTgRowDelayMin,
    appnCosTgRowDelayMax,
    appnCosTgRowUsr1Min,
    appnCosTgRowUsr1Max,
    appnCosTgRowUsr2Min,
    appnCosTgRowUsr2Max,
    appnCosTgRowUsr3Min,
    appnCosTgRowUsr3Max
}
STATUS current
DESCRIPTION
  "The appnCosConfGroup is mandatory only for APPN network
  nodes and end nodes."
::= { appnGroups 12 }

appnIntSessConfGroup      OBJECT-GROUP
  OBJECTS {
    appnIsInGlobeCtrAdminStatus,
    appnIsInGlobeCtrOperStatus,
    appnIsInGlobeCtrStatusTime,
    appnIsInGlobeRscv,
    appnIsInGlobeRscvTime,
    appnIsInGlobeActSess,
    appnIsInSessState,
    appnIsInPriLuName,
    appnIsInSecLuName,
    appnIsInModeName,
    appnIsInCosName,
    appnIsInTransPriority,
    appnIsInSessType,
    appnIsInSessUpTime,
    appnIsInCtrUpTime,
    appnIsInP2SFmdPius,
    appnIsInS2PFmdPius,
    appnIsInP2SNonFmdPius,
    appnIsInS2PNonFmdPius,
    appnIsInP2SFmdBytes,
```

```

    appnIsInS2PFmdBytes,
    appnIsInP2SNonFmdBytes,
    appnIsInS2PNonFmdBytes,
    appnIsInPsAdjCpName,
    appnIsInPsAdjTgNum,
    appnIsInPsSendMaxBtuSize,
    appnIsInPsSendPacingType,
    appnIsInPsSendRpc,
    appnIsInPsSendNxWndwSize,
    appnIsInPsRecvPacingType,
    appnIsInPsRecvRpc,
    appnIsInSsAdjCpName,
    appnIsInSsAdjTgNum,
    appnIsInSsSendMaxBtuSize,
    appnIsInSsSendPacingType,
    appnIsInSsSendRpc,
    appnIsInSsSendNxWndwSize,
    appnIsInSsRecvPacingType,
    appnIsInSsRecvRpc,
    appnIsInSsRecvNxWndwSize,
    appnIsInRouteInfo
}
STATUS current
DESCRIPTION
  "The appnIntSessConfGroup is mandatory only for network
  nodes."
::= { appnGroups 13 }

appnHprBaseConfGroup   OBJECT-GROUP
  OBJECTS {
    appnNodeHprtIntRteSetups,
    appnNodeHprtIntRteRejects,
    appnLsErrRecoSup,
    appnLsForAnrLabel,
    appnLsRevAnrLabel
  }
STATUS current
DESCRIPTION
  "The appnHprBaseConfGroup is mandatory only for nodes that
  implement the HPR base (APPN option set 1400)."
::= { appnGroups 14 }

appnHprRtpConfGroup   OBJECT-GROUP
  OBJECTS {
    appnNodeMaxSessPerRtpConn,

```

```

        appnNodeHprOrgRteSetups,
        appnNodeHprOrgRteRejects,
        appnNodeHprEndRteSetups,
        appnNodeHprEndRteRejects,
        appnLsBfNceId
    }
STATUS current
DESCRIPTION
    "The appnHprRtpConfGroup is mandatory only for nodes that
     implement the HPR RTP tower (APPN option set 1401)."

::= { appnGroups 15 }

appnHprCtrlFlowsRtpConfGroup      OBJECT-GROUP
    OBJECTS {
        appnLsCpCpNceId,
        appnLsRouteNceId
    }
STATUS current
DESCRIPTION
    "The appnHprCtrlFlowsRtpConfGroup is mandatory only for nodes
     that implement the HPR Control Flows over RTP tower (APPN
     option set 1402)."

::= { appnGroups 16 }

appnHprBfConfGroup      OBJECT-GROUP
    OBJECTS {
        appnIsInGlobeHprBfActSess,
        appnIsInRtpNceId,
        appnIsInRtpTcid,
        appnIsRtpSessions
    }
STATUS current
DESCRIPTION
    "The appnHprBfConfGroup is mandatory only for nodes that
     implement the APPN/HPR boundary function."

::= { appnGroups 17 }

appnTrapConfGroup      OBJECT-GROUP
    OBJECTS {
        alertIdNumber,
        affectedObject
    }
STATUS current
DESCRIPTION
    "The appnTrapConfGroup is optional for all APPN nodes.  Nodes

```

implementing this group shall also implement the appnTrapNotifGroup."

::= { appnGroups 18 }

appnTrapNotifGroup NOTIFICATION-GROUP
NOTIFICATIONS {
 alertTrap
}
STATUS current
DESCRIPTION
 "The appnTrapNotifGroup is optional for all APPN nodes.
 Nodes implementing this group shall also implement the
 appnTrapConfGroup."

::= { appnGroups 19 }

END

5. Acknowledgments

This MIB module is the product of the IETF SNA NAU MIB WG and the AIW APPN/HPR MIBs SIG. Thanks to Wayne Clark, Cisco Systems; Jim Cobban, Nortel; Rich Daugherty, IBM Corporation; Mark Regan, Cisco Systems; and Leo Temoshenko, IBM Corporation, for their contributions and review.

6. References

- [1] SNMPv2 Working Group, Case, J., McCloghrie, K., Rose, M., and S. Waldbusser, "Structure of Management Information for version 2 of the Simple Network Management Protocol (SNMPv2)", RFC 1902, January 1996.
- [2] SNMPv2 Working Group, Case, J., McCloghrie, K., Rose, M., and S. Waldbusser, "Textual Conventions for Version 2 of the Simple Network Management Protocol (SNMPv2)", RFC 1903, January 1996.
- [3] SNMPv2 Working Group, Case, J., McCloghrie, K., Rose, M., and S. Waldbusser, "Conformance Statements for Version 2 of the Simple Network Management Protocol (SNMPv2)", RFC 1904, January 1996.
- [4] IBM, Systems Network Architecture Technical Overview, GC30-3073.
- [5] IBM, Systems Network Architecture APPN Architecture Reference, SC30-3422
- [6] IBM, Systems Network Architecture Formats, SC30-3346.
- [7] Allen, M., Clouston, B., Kielczewski, Z., Kwan, W., and B. Moore, "Definition of Managed Objects for APPC", RFC 2051, Wall Data Inc., Cisco Systems, Jupiter Technology Inc., IBM Corporation, December 1995.
- [8] Kielczewski, Z., Kostick D., and K. Shih, "Definition of Managed Objects for SNA NAUs using SMIv2", RFC 1666, Eicon Technology Corporation, Bell Communications Research, Novell, August 1994.
- [9] Clouston, B., and B. Moore, "Definitions of Managed Objects for DLUR", November 1996.
- [10] Clouston, B., and B. Moore, "Definitions of Managed Objects for HPR", November 1996.

- [11] SNA DLC Services MIB Working Group, Hilgeman, J., Nix, S., Bartky, A., and W. Clark, "Definitions of Managed Objects for SNA Data Link Control (SDLC) using SMIv2", RFC 1747, January 1995. URL: <ftp://ds.internic.net/rfc/rfc1747.txt>
- [12] SNA DLC Services MIB Working Group, Berl, S., Nix, S., and W. Clark, "Definitions of Managed Objects for SNA Data Link Control: LLC", May 1995.
- [13] Chen, D., Gayek, P., and S. Nix, "Definitions of Managed Objects for Data Link Switching using SNMPv2", RFC 2024, October 1995.
- [14] IBM, Systems Network Architecture Management Services Formats, GC31-8302.

7. Security Considerations

In most cases, MIBs are not themselves security risks; if SNMP security is operating as intended, the use of a MIB to view information about a system, or to change some parameter at the system, is a tool, not a threat.

None of the read-only objects in the APPN MIB reports a password, user data, or anything else that is particularly sensitive. Some enterprises view their network configuration itself, as well as information about network usage and performance, as corporate assets; such enterprises may wish to restrict SNMP access to most of the objects in the MIB.

Four of the read-write objects in the MIB can affect network operations; it is recommended that SNMP access to these objects be restricted. The four objects are:

- o appnNodeNnSafeStoreFreq: Setting this object to 0, or to a very large value, effectively turns off safe storing of topology data.
- o appnPortCommand, appnLsCommand: These two objects allow an APPN port or link station to be activated, deactivated, or recycled via an SNMP operation. The latter two operations may disrupt current users of the network.
- o appnIsInSessState: Setting this object to 'inactive' causes an active SNA session to be deactivated.

Other read-write objects control the gathering of network management data; controlling access to these objects is less critical.

8. Authors' Addresses

Bob Clouston
Cisco Systems
7025 Kit Creek Road
P.O. Box 14987
Research Triangle Park, NC 27709, USA

Tel: 1 919 472 2333
E-mail: clouston@cisco.com

Bob Moore
IBM Corporation
800 Park Offices Drive
CNMA/664
P.O. Box 12195
Research Triangle Park, NC 27709, USA

Tel: 1 919 254 4436
E-mail: remoore@ralvm6.vnet.ibm.com

